

# Owner's Manual

## Wall Switch Style RF Controller, 433MHz

MODEL: 47-1013A-T, 47-1013B-T

FCC ID: ELY547-47-1013-T

IC 1492A-471013T

### REMOTE CONTROL

The remote control has a range of approximately 50 ft. (15.25m), it does not have to be pointed at the fireplace and can pass through most obstacles (including walls).

### BATTERY INSTALLATION

1. Depress tab on the battery cover on the side of the remote transmitter and remove battery cover.
2. Install 2 AAA batteries into the remote control. (included)
3. Replace the battery cover.

### AC24V INSTALLATION

1. Depress tab on the cover on the back of the remote transmitter and remove the wire compartment cover.
2. Remove the 2 lead wires from the wire compartment.
3. Connect the wires to the AC24V hard wires.
4. Replace the cover.

**Note:** There is an internal electronic switch to disconnect the AAA Battery power supply when the AC24V~ hard wire hook up is made.

### FLAME ON/OFF BUTTON



Press the right ▲ to turn the Flame ON or press the left ▼ to turn the Flame OFF.

### PURIFIRE ON/OFF BUTTON



(For 47-1013A-T version only)

Press the right ▲ to turn the Purifire ON or press the left ▼ to turn the Purifire OFF.

### COUNTDOWN TIMER








(For 47-1013B-T version only)

To set the Countdown timer, press the left ▼ or right ▲ buttons to decrease or increase by 30 minute decrements or increments. The countdown timer can be set from 30

minutes to 6 hours. The fireplace will automatically turn OFF when the sleep timer reaches 0 minutes.

## SET TEMPERATURE

Press the left  or right  direction button together of  to select between °F and °C.

Press the left  or right  direction button to decrease or to increase temperature. Temperature Range 0 °C - 37 °C (32 °F - 99 °F).

## CAUTION

1. For indoor use in dry areas only.
2. 24 volt AC supply.

**WARNING**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**

- (1) This device may not cause harmful interference, and**
- (2) This device must accept any interference received, including interference that may cause undesired operation.**

**SPECIFICATIONS**

Input Rating.....	AC 24V~ or DC3V (Alkaline AA x 2)
Operation Temperature.....	-10 to 70°C
Storage Temperature .....	-25 - 60°C