

Size: 10.7x25.6(H)cm

SKU NR. RC004/TR009 REMOTE CONTROLLER

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

SPECIFICATIONS

Frequency	---	315MHz
Transmitter Power Input	---	DC 12V Alkaline Battery (Size 23A)
Receiver Power input	---	AC 125V Electrical Outlet
Receiver Power Output	---	13 Amps / 125 Volts Resistive
		13 Amps / 125 Volts General Purpose
		1000W Tungsten

Remote control unit




RF (radio frequency) transmitter is powered by one 12V alkaline battery

Red indicator light 1. flickers when transmitting.


Remote operates the indoor receiver/switch.

Chain and key ring 2. for pocket or purse key ring use



Replace battery when red indicator light 1. does not flicker when a button is pressed. Remove battery cover a. to replace the A23 12V battery b.

Indoor receiver/switch



Plug the indoor receiver/switch into an in-wall outlet 3. then plug the lights or device to be switched into the 2 outlets indoor receiver/switch 4. Let the switch plug downward so moisture doesn't accumulate in the outlet. Red indicator light 5. is lit when the outdoor receiver/switch is on.

Caution:

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment with is not to be used for an extended period of time.
- Remove used batteries promptly.
- Battery contains mercury. Do not put in trash. Recycle or manage as hazardous waste.