




FIRETECH

5F60A8E



SAFETY PRECAUTIONS (keep manual for future reference)

This vehicle is not recommended for children under the age of 6 years. Please read all of the instructions before operating this vehicle. Always follow general safety rules while operating vehicle: avoid hitting pets, furniture or people. Do not pick up vehicle while it is in motion; keep hands, hair, and clothing away from this vehicle when the power switch is turned to the " I " (ON) position. Remove batteries when vehicle is stored. Avoid tire contact on painted or varnished surfaces.

The FIRETECH™ is built with an automatic shut-off function if the vehicle reaches excessive temperature during operation. If the vehicle stops after a prolonged period of operation, turn off vehicle and controller, remove batteries from vehicle and cease operation for ten (10) minutes. Reinsert batteries and resume play.

FCC NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

U.S FCC Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

" Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. "

Carrier frequency and field strength:


Frequency Channel: 27.145MHz

27.145MHz Field Strength: 68.7 dB μ v/m @ 3m.


TRY-ME FOR LIGHT UP FLAME

On the vehicle bottom, switch to “□”(Try-me) position, press Try-me button on top of body


NOTE: THE BATTERIES INCLUDED IN THIS TOY ARE INTENDED FOR IN-STORE DEMONSTRATION PURPOSE ONLY.



Push Down Try-Me Button Here



Flame Spurt Out and Rocket Light On!



CHANGE TO “LIGHT-UP FLAME FIRES OUT”



BATTERY REQUIREMENTS / INSTALLATION FOR VEHICLE

To operate your vehicle you will need 6 x 1.5 Volt alkaline AA / LR6 batteries (not included).

1. On the vehicle bottom, unscrew and remove the battery cover.
2. Take out all batteries from compartment and insert 6 new AA/LR6 batteries.
3. Close battery cover and tighten screw.
4. Turn power switch to the " I " (ON) position.

NOTE: THE BATTERIES INCLUDED IN THIS TOY ARE INTENDED FOR IN-STORE DEMONSTRATION PURPOSE ONLY

For best performance, use of alkaline batteries is recommended.





BATTERY AND ANTENNA INSTALLATION FOR TRANSMITTER

To operate your transmitter you will need 1 x 9 Volt battery (not included).

NOTE: for best performance, use of alkaline batteries is recommended.

1. Unscrew battery cover as show and remove battery cover.
2. Install 1 new 9V battery. Close battery cover and tighten the screw on battery cover.
3. Move the power button to the " I "(ON) position and the red LED light will come on.
This will show you that the battery is good and the transmitter is ready for operation.
PLEASE NOTE: Vehicle power switch must be in the " I " (ON) position to receive commands from the transmitter.
4. Change batteries when LED is dim or not on.
5. Insert the antenna into the top of transmitter, tighten it by rotating clockwise(viewing from top of transmitter).







SAFETY PRECAUTIONS


- Non-rechargeable batteries are not to be recharged;
- Rechargeable batteries are only to be charged under adult supervision;
- Rechargeable batteries are to be removed from the toy before being charged;
- Different types of batteries or new and used batteries are not to be mixed;
- Batteries are to be inserted with the correct polarity (+ and -);
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries;
- Dead batteries are to be removed from the toy;
- The supply terminals are not to be short-circuited;
- Only use batteries recommended by the manufacturer or batteries of an equivalent type;
- Please remove batteries from the toy if it is not be used over a long period of time;
- Protect the environment: Bring used batteries to a special collecting point! Thank you!

HOW TO PLAY

1. Move the power button to the " I " (ON) position both for transmitter and vehicle.
2. Move control buttons as indicated by solid arrows. Vehicle will move forward / backward, turn left / right.
3. Flame will spurt out / draw back and rocket light will ON /OFF while move forward / backward(or stop).
4. If the vehicle does not run in straight line, adjust DIRECTION ADJUSTMENT on the vehicle chassis.



CHANGE TO "FLAME FIRES OUT AND MOVES FORWARD"



CHANGE TO "FLAME DRAWS BACK WHILE MOVING BACKWARD"

PROPER OPERATION AND STORAGE OF YOUR VEHICLE

1. Best operation of vehicle is on clean and dry surface.
2. Always operate your vehicle within a 50 feet range.
3. Always operate your vehicle on dry surfaces away from cars and other full-size vehicles
4. Always store your vehicle in a cool ,dry place and off of painted or varnished surfaces..
5. Avoid operating around CB radios, high voltage electrical wires, and large steel -reinforced concrete buildings.
6. Avoid operating your vehicle and another vehicle on the same frequency.
7. DO NOT use in water.
8. Vehicle and transmitter are not waterproof. Do not immerse or use in water.