CHOOSING YOUR PLAYING LOCATION

You can operate your Mini Vortex indoors or outdoors. The Mini Vortex is designed to operate in most rugged conditions and terrains. Do not operate your Mini Vortex on roads or any areas where there are cars. Operating your Mini Vortex on roads or any areas with cars is extremely dangerous and most likely illegal! The Mini Vortex is not water resistant. Do not operate your Mini Vortex in any wet conditions, mud, puddles, rain or any other form of precipitation or harsh weather. The Mini Vortex has open Cooling Vents in some strategic locations. If water gets into these Cooling Vents, the Mini Vortex could sustain damage. If operating your Mini Vortex indoors, be careful to avoid contact with any objects such as furniture, plants, electronics, and any other items which can break easily. The Mini Vortex is capable of some relatively high speed stunts and could easily damage some household objects. Avoid operating your Mini Vortex around pets or people, and especially crowds. If the Mini Vortex is stepped on or otherwise crushed, it will sustain damage. Ensure that people around you are aware that you are playing with your Mini Vortex. Be aware of changes in your operational environment and play safe! The radio control range of your Mini Vortex is up to 40M, and varies depending on interference within the operational environment. WARNING: The relatively high speed stunts of the Mini Vortex are capable of damaging or injuring plants, furniture, pets or people so play carefully.

Performance Tips

- 1. Do not drive on grass, dirt, sand, dusts, carpet or go through water.
- 2. Do not drive in windy or rainy weather.
- 3. Avoid direct impact the Vehicle with obstacles.
- 4. Switch OFF the power when not in use to prevent damage of Vehicle and Transmitter due to leakage of electrolyte from batteries.
- 5. Remove all batteries from the Vehicle and Transmitter when not in use for long period.
- 6. Keep fingers, hair and loose clothing away from wheels.
- 7. The operating range can be affected by a variety of factors a) Low Voltage of batteries in Transmitter or Vehicle b) Interference from other items that emit radio frequency signals.
- 8. Outdoor usage is recommended in order to get optimum control range.
- 9. Recommend to play the vehicle on a clean and smooth surface.
- Clean the battery compartment to make sure it is free from dust to prevent poor contact of batteries

Cautions

- Do not attempt to disassemble the Vehicle or Transmitter.
- Do not operate the Vehicle with same frequency with other player(s) in same location that will interfere and make the Vehicle out of control.
- Make sure the batteries are installed with correct polarities (+/-) as shown inside the battery compartment.
- Remove the package and take out all accessories before giving the Vehicle and Transmitter to child to play.



The packaging and instruction manual contain important information. Please keep them for future reference. Warning! Choking Hazard. Not suitable for children under the age of 3 years due to small parts.

We reserve the right to improve/amend specifications and colors without notice.

FCC label compliance statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-210 Compliance Statement:

This device complies with Industry Canada Licence - exempt RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Declaration of Conformity

The product is in conformity with the requirement of EU Directive 2014/53/EU.

Environmental notes:

The whole product also does not belong to household waste at the end of the product life.

You can return it at collection points for the recycling of electronic and electronical instruments

The symbol on the item, instruction manual, hangtag or packing is showing this clearly.

Materials should be recycled according to their respective markings.

Recycling of old devices or other re-use of materials contained therein represents an important contribution to environmental protection. Please ask at your local community for the correct collection point.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold. You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

Pb=Battery contains lead Cd=Battery contains cadmium

Hg=Battery contains mercury

Frequency band: 2405 - 2475 MHz Maximum radio frequency power transmitted: <0 dBm

Conforms to the safety requirements of ASTM F963






KIDZTECH TOYS MANUFACTURING LTD.
Room 1201,12/F, Inter-Continental Plaza,
94 Granville Road, TST East, Hong Kong.
Tel: (852) 27218868 info@kidztech.net



NO. 84182








Tyre Inflation Gauge



Vehicle:

 1 x 6.4V Lithium Ion rechargeable battery pack (Included)

2. Transmitter: 1 x 9V battery (Included)









Charging the Rechargeable Battery Pack for the Vehicle

- 1. Connect the 6.4V rechargeable battery pack to the battery charger via the USB adapter charger.
- 2. Recommend use Computer connect USB cable to charge the battery. If use adaptor connect USB cable to charge the battery, the adaptor output limited cannot exceed 6.4V.
- 3. The charging time for a full charge is about 2 hours.
- 4. When charging is completed, unplug the charger from the AC socket.
- 5. Disconnect the rechargeable battery pack form the battery charger and the USB cable.



- Be Sure To Charge Battery Pack Before Using.
- If Battery Pack Is Hot After Use, Allow To Cool Before Recharging.
- Do Not Dispose Of Battery Pack In Fire.
- Do Not Recharge Battery Pack That Shows Leakage Or Corrosion, Or Attempt To Open Battery Pack.