

REMOTE CONTROL (Default)

Button Functions Conditions

Press button 1 once

- a. Arm & lock doors
- b. Stop alarm trigger temporarily
- c. Lock/Unlock door
- a. ACC Off
- b. Sounding
- c. During driving/ Valet mode

Press button 1 then 3 within 2 sec Arm bypassing shock sensor ACC Off

Press button 1 then 2 within 2 sec

Arm bypassing shock sensor and door
trigger input

ACC Off

Press button 2 once

- a. Disarm & unlock doors
- b. Stop alarm trigger temporarily
- a. Armed
- b. Sounding

Press and hold button 4 for 2 sec. Trunk release ACC Off

Press and hold button 1 once for 3 sec. Car finder Armed

Press and hold button 3 for 3 sec Remote panic ACC Off

Press and hold button 1 and button 2 for 3 sec Enter anti carjacking ACC On

Press button 3 then 1 within 2 sec Silent arming ACC Off

Press button 3 then 2 within 2 sec Silent disarming Armed

Press button 3+4 3rd Channel out put Anytime

FCC ID: YYYKLEMA-675

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.