

LED Display

Pairing	Blue LED flashes quickly
Paired	Blue LED flashes slowly
AUX IN, BT standby	Blue LED flashes slowly
Charging	Red LED on, then turns off when fully charged
Battery Low	Red LED flashes slowly (see Battery recharging)

Bluetooth Pairing

1. After you have connected your headphone or speaker cable to the BT-100R, you can turn on the BT-100R by switching the slide switch to “On” and the blue LED will flash slowly. When it

ENGLISH

starts to flash quickly, this means it is entering pairing mode.

2. When you activate your device's Bluetooth function, it will begin to search for the device. You will find "Genius BT-100R" on your device's Bluetooth list and then you can connect it.

3. When pairing is successful, the blue LED will flash slowly.

Note 1: Most devices do not require you to key in the pin code. If a pin code is required, key in "0000".

Battery recharging

If the lithium battery is low and requires charging, just attach the USB cable to the receiver and your PC/notebook.

Bluetooth music receiver connects wired speakers/headphone to Bluetooth music devices

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

ENGLISH

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- _ Reorient or relocate the receiving antenna.
- _ Increase the separation between the equipment and receiver.
- _ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- _ Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

undesired operation.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Only use attachments/accessories specified by the manufacturer.
10. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION :

Danger of explosion if battery is incorrectly replaced. Replace only

ENGLISH

with the same or equivalent type.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

