

一、Operation Description

1. The USB power plug of speaker is plugged in.



2. Turn on the power and enter the LINE function by default. The red LED is always on.

At this time, the audio cable can be inserted into the audio device to play music.

Short press the **+** button on the remote control to increase volume; long press the **+** to increase volume continuously. And short press the **-** button on the remote control to decrease volume; long press the **-** to decrease volume continuously.

3. Short press  button on the remote control to enter the Bluetooth status, and

the blue and red LEDs will flash alternately. At this time, you can pair the Bluetooth device. After the pairing is successful, there will make a notification sound. The blue

LED is always on. At this time, the audio device can play music. Short press 

button on the remote control to stop playing music, click again to resume playback.

Short press **+** on the remote control, increase the volume, press twice consecutively to go to the previous song, long press **+** on the remote control to increase the volume, and the speaker sounds louder. Short press **-** on the remote control, the volume decreases, press twice, Go to the next song, press and hold **-** button on the remote control to decrease the volume, and the speaker sound is reduced.

4. After press  button on the remote control to enter the Bluetooth mode. If there is a paired device, it will return to the paired device. If there is no paired device, it will enter the pairing mode.

5. **Pairing** In the Bluetooth status, long press  button on the remote control for 3 seconds. When the speaker will make a notification sound, it indicates that the current pairing device is released and the pairing mode is entered. The blue and red LEDs flash alternately. At this time, Bluetooth device pairing can be performed.

6. TWS Operation Function

Two speakers are powered on. Enter the Bluetooth mode, set one as the master speaker, and the other as the slave speaker. The slave speaker must be in the state without any equipment connected, and the master speaker is unlimited. There are connected devices and no connected devices. Long press the  key on the main speaker for 3 seconds. At this time, the main speaker will make a notification sound, and the two speakers can be connected. When the slave speaker is connected to the main speaker, the slave speaker will emit two beeps, indicating that the connection is successful. After the speakers are connected, if the main speakers have connected devices and the two speakers have blue LEDs on, the master speakers can control the slave speakers and play. If there is no equipment connected to the main speaker, the blue and green LEDs of the two speakers will flash alternately. At this time, the main speaker must be connected to audio equipment. The main speaker is connected to audio equipment. The two speakers have blue LEDs on. The main speaker can control the slave speakers and can also play.

Turn off TWS Function:

Long press  key on the main speaker for more than 3 seconds. After a notification sound from the speaker, the blue and red LEDs on the secondary speaker flash alternately, indicating that the TWS function is disabled.

7. Pairing, TWS, previous song, next song these functions only work under Bluetooth status.


8. After power on, short press  button on the remote control to enter the Bluetooth mode, short press the  button on the remote control to enter the LINE mode.

9. Reset :

(If the TWS has been paired, please release the TWS function first, the reset function can work normally.) In the Bluetooth status, press and hold the  and  keys for 3 seconds, there will make a notification sound, which means that all memories have been cleared and the Bluetooth state is entered. The red LED flashes and you can pair the Bluetooth device.

10. Turn off: Unplug the power supply and the LED is off.

二、Button Function



	Status	Function	Button Operation	Description
1	Turn off	Turn on	The red LED is on when the USB power code of speaker is plugged in, and enters LINE mode by default	The red LED is on when you turn on, and enters LINE mode
	Power on	Bluetooth	Short press 	Blue and red LEDs flash alternately and enter pairing status.
	Power on	Line	Short press 	Red LED always on, enters to LINE mode
	Power on	Turn off	Unplug power	LED turn off
2	Bluetooth / Line	Increase Volume	Short press the 	Short press the  button to increase volume
			Long press the 	Long press the  to increase volume continuously.
3	Bluetooth / Line	Decrease Volume	Short press the 	Short press the  button to increase volume
			Long press the 	Long press the  to increase volume continuously.
4	Bluetooth	Previous Track	Double-click 	Enter to previous track
5	Bluetooth	Next Track	Double click 	Enter to next track
6	Play music	Pause	Short press the 	Short press  button to stop playing music, click again to resume playback.
	Line	Mute	Short press the 	Short press the  button enters to mute status. Press it again, the music unmute.
7	Bluetooth	PAIR	Long press  button for 3 seconds	When the speaker will make a notification sound it means that the current pairing device is canceled; the blue and red LEDs flash

	Status	Function	Button Operation	Description
				alternately, enters the pairing status.
	Bluetooth	Reset	Long press and hold the + and - keys for 3 seconds	(If the TWS has been paired, please release the TWS function first, the reset function can work normally.) In the Bluetooth status, press and hold the + and - keys for 3 seconds, there will make a notification sound, which means that all memories have been cleared and the Bluetooth state is entered. The red LED flashes and you can pair the Bluetooth device.
8	Bluetooth	TWS	Long press ▶ key for 3 seconds	Long press ▶ key for 3 seconds. After a notification sound from the speaker, the LED flash alternately, enters TWS pairing status. Long press ▶ key on the main speaker for more than 3 seconds. After a notification sound from the speaker, the blue and red LEDs on the secondary speaker flash alternately, indicating that the TWS function is disabled.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body