


Getting Started:

1. Before you can use this device, it needs to be charged, so connect the micro USB cable to Ring Pointer and any USB port on your PC. It takes approximately two hours to fully charge.
2. Connect the pico receiver to a USB port of a PC or notebook.
3. Make sure that you have turned on the power switch.

**Button definitions:**

| Button Name | | Button/Switch Function |
|---------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| P1 | | Previous Page |
| P2 | | F5 (Play) /ESC |
| P3 | | Next Page |
| P4 | | Laser Pointer |
| P5 | Other | Blank Screen |
| | Power Function | On-Off (Power On/Off, press for 3 seconds) |
| LED indicator | | <ol style="list-style-type: none"> 1. Charging status <ol style="list-style-type: none"> a. Charging: LED always ON b. Fully charged: LED turns off 2. Low battery -flashing light (low speed) |



LED indicator

Presenter Mode Button Definition

P1: Press P1 to return to previous PowerPoint page.

P2: Press P2 to play the PowerPoint file and press again to exit the file.

P3: Press P3 to go to next PowerPoint page.

P4: Press P4 for laser pointer function

P5: Press P5 for blank screen or power on-off function: press for three seconds to change function.

✖ Note: This mode works in Microsoft Office PowerPoint.

Battery Low indicator

When the power level is low, the Blue LED below the touch panel will flash to remind you that you need to recharge Ring Pointer as soon as possible

FCC ID: FSUGMZK5**FCC Compliance and Advisory Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

1. Reorient the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

IC statement: This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.