
Issue department: Bedding Division	Date:	2016-11-21
Product Function	Author:	Jarek
instruction	No: CU358-2-P	
CU358-2-P	Version:	1.0

JLDP.15.005.401 Function instruction

1. Electrical configuration diagram:



Remote Control JLDK.30.04.05



Issue department: Bedding Division	Date:	2016-11-21
Product Function	Author:	Jarek
instruction	No: CU358-2-P	
CU358-2-P	Version:	1.0
	Page 2 of 5	

2. Function Picture



1. Process of test

1.1. Power

Connect to the 29V DC;

1.2. MULTIFUNCTION port

Connect with the same other Control box or Other accessories;

Issue department: Bedding Division	Date:	2016-11-21
Product Function	Author:	Jarek
instruction	No: CU358-2-P	
CU358-2-P	Version:	1. 0
CU350-2-P		

1.3. Power LED & PAIRING LED

Power supply for control box, PAIRING LED of control box flashes for 4 times, and then turns off, POWER LED turns on .

1.4. RESET button

Double click RESET button, pairing LED turns on, the control box enters into mode of code paring;

Press and hold the paring LED, the backlight of paring LED flashes, the backlight of remote flashes, the remote enters into mode of code paring;

The backlight of paring LED of remote stops flashing, and the paring led of control box turns off, it indicates that the code paring is successful;

Is fails, repeat all the processes above;

1.5. HEAD actuator port

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released;

Click head down button, head actuator moves in, stop when released;

1.6. FOOT actuator port

Connect to foot actuator, control by remote single:

Click foot up button, foot actuator moves out, stop when released;

Click foot down button, foot actuator moves in, stop when released;

1.7. Test for underbed light

Click button of underbed light, turns on(or turns off) the underbed light, switch the status once when click once;

1.8. FLAT function

Press and release the FLAT button on remote, the head and foot actuators moves to lower position(when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once), stop when press any buton;

Issue department: Bedding Division	Date:	2016-11-21
Product Function	Author:	Jarek
instruction	No: CU358-2-P	
CU358-2-P	Version:	1. 0

1.9. ZERO G position function

Press and release ZERO G button on remote, the head and foot actuator moves to preset memory position, stop when press any button;

1.10. LOUNGE position function

Press and release LOUNGE on remote, the head and foot actuator moves to preset memory position, stop when press any button;

1.11. TV position function

Press and release TV on remote, the head and foot actuator moves to preset memory position, stop when press any button:

Issue department: Bedding Division	Date:	2016-11-21
Product Function	Author:	Jarek
instruction	No: CU358-2-P	
CU358-2-P	Version:	1. 0

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.