



# Mini Radio Control Formula One™

**AGES  
5+**

## OPERATING INSTRUCTIONS

### BATTERY INSTALLATION FOR CONTROLLER

1. Unscrew the battery compartment cover of remote controller with a screwdriver. **(Diagram 1)**
2. Install 3 x 1.5V (AA-LR6) alkaline batteries with polarity as shown inside battery compartment cover.
3. Screw on battery compartment cover.

### TO PLAY

1. Screw antenna onto the remote controller.
2. Push the power switch of remote controller to "ON" position **(Diagram 2)**.
3. Red LED on the remote controller will turn on to indicate that the unit is ready.
4. Install 4 x 1.5V (AAA-LR03) alkaline batteries into the charger with polarity as shown in **(Diagram 3)**. To charge the vehicle, pull the extension plug from the charger and plug into the contact point which is located at the bottom of the vehicle. Snap in the charger at the back of the remote controller. Align the "▼" marking on the plug to the "▲" marking next to the contact point for correct alignment. **(Diagram 4)**
5. The green LED on the charger will light up when the vehicle is in charging status. When it goes out, the vehicle has completed charging. Disconnect the charger with the vehicle once after the charging completed. Do not store the vehicle with the charger connected.
6. Turn the steering wheel to adjust the direction of driving. **(Diagram 5)**
7. Pull the trigger to make the vehicle go forward.
8. Push the trigger to make the vehicle go backward.
9. Operate your vehicle in a dry, clean, flat open area. Avoid sand and water.
10. If vehicle does not respond to remote controller, try to operate the vehicle at a closer range (The normal operating range is around 2m-5m).
11. Turn the power switch to "OFF" position when unit is not in use.

Diagram 1




Diagram 2




Diagram 3





Diagram 4



### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation.

Hereby, Kid-Riffic Toys Ltd., declares that this Micro R/C Formula One™ is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.


© 2003 Kid-Riffic Toys Ltd.  
All Rights Reserved.  
8348C Olive Blvd.,  
St. Louis, MO 63132, USA  
www.KID-RIFFIC.com  
Toll Free No.: 1-888-565-1777

MADE IN CHINA

### BATTERY PRECAUTIONS:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Check and replace batteries periodically to prevent corrosion.
- Keep unit away from extreme heat.
- Do not dispose of batteries in fire, batteries may explode or leak.

Diagram 5



**WARNING:**

**CHOKING HAZARD - Small parts.  
Not for children under 3 years.**

