

# **OPERATING INSTRUCTIONS**

## BATTERY INSTALLATION FOR CONTROLLER

- Unscrew the battery compartment cover of remote controller with a screwdriver.
- Install 3 x "AA" (1.5V) alkaline batteries with polarity as shown inside battery compartment.
- Screw on battery compartment cover.

#### TO PLAY

- 1. Screw antenna onto the remote controller.
- 2. Push the power switch of remote controller to "ON" position.
- 3. Red LED on the remote controller will turn on to indicate that the unit is ready.
- 4. Pull the extension plug of remote controller to plug in the contact point which is located at the bottom of the vehicle for charging battery.
  - Red LED on remote controller will turn on when unit is in charging status.
- 6. Charge for approximate 45 seconds with 2 minutes running.
- 7. Extend the antenna of controller for having a better reception.
- 8. Turn the steering wheel clockwise, turn the vehicle wheel right.
- 9. Turn the steering wheel counter-clockwise, turn the vehicle wheel left.
- 10. Pull the trigger to make the vehicle go forward.
- 11. Push the trigger to make the vehicle go backward.
- 12. Operate your vehicle in a dry, clean, flat open area. Avoid sand and water.
- 13. If vehicle does not respond to remote controller, try to operate the vehicle at a closer range (The normal operating range is around 2m - 5m).
- 14. Adjust the driving turning angle by turning the white regulator which located at the bottom upper portion of the vehicle.
- 15. A slot is provided to fasten vehicle on the controller, then with belt clip that player can carry it all around.
- 16. Turn switch of remote controller to "Off" position when unit is not in use.

#### OMPLIANCE WITH FCC REGULATIONS (VALID IN U.S. ONLY - VALABLE AUX E. U. SEULEMENT)

This device complies with Part 15 FCC Rules. Operation of this device is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- This device must accept any harmful interference that may cause undesired operation.

This device generates and uses radio frequency energy and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC which are designed to provide reasonable protection against such interference.

#### BATTERY PRECAUTIONS

- Do not use rechargeable batteries.
- Do not attempt to recharge the batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not short circuit battery contacts.
- When not in use, remove batteries to prevent possible leakage.
- Exhausted batteries are to be removed from the game unit.
- Do not dispose of batteries in fire, batteries may explode or leak.



#### CAUTION:


FCC Regulations state that changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. (VALID FOR CANADA ONLY - VALABLE AU CANADA SEULEMENT) This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.


(2) This device must accept any harmful interference that may cause undesired operation.

© 2002 Kid-Riffic Toys Ltd. All Rights Reserved. Patent Pending 8348Č Olive Blvd., St. Louis, Mo. 63132, USA Toll Free No.: 1-888-565-1777







П




See Point 6 - 9



See Point 14



See Point 15









### **OPERATING INSTRUCTIONS**

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment had been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency, may cause harmful interference to radio communications.

However, there is no generate that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

Print in China.