



## Product/Controls Diagram



- 1 Power on/off & Play/Pause & Answer/End Call
- 2 Charging thimble port

## Wearing Schematic



### Headphone Specification:

Frequency Response: 20Hz to 20KHz  
Driver Size: 10mm  
Impedence: 16ohm  
Weight: 60g

### Battery Information:

Built-in Bluetooth: Lithium  
Input: DC 5V/50mA  
Music playing time: Up to 3 Hours  
Charging time: 1.5 Hours  
\* Approximate Playback time depends on individual use and may be more or less than the time specified.

### Bluetooth Information:

Bluetooth version: V3.0  
Operation distance: 10 Meters  
System Requirements: Bluetooth-capable device

### Additional Connection Sources:

Power Source: Built-in rechargeable battery or via thimble port from charging case

### Charging

- Put headsets in charging box and press the power button, the LED indicator on upper-right of charging box flashing in blue, cover the box lid, LED light will appear beneath earbuds power button to indicate when the earbuds are charging, even while earbuds are turned off.
- When charging is complete, the LED light will turn a solid blue.
- Charging time is approximately 1.5 hours.

**NOTE: When connected to an Apple device, the battery level will show on your screen next to the Bluetooth icon.**

### Power on

- Press & hold the power button on the earbuds (both left and right at the same time) for 5 seconds to turn on the earbuds, the LED light will flash blue & red and the earbuds will emit a tone.

**NOTE: If your earbuds are already turned on, you must first power off the earbuds before completing the above step.**

- After a few seconds the LED lights beneath power button will flash in blue, left channel and right channel has connected and ready to pair with a Bluetooth-enabled device.

### Pair & Connect with a New Device

- On your Bluetooth-enabled smartphone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.
- After a few seconds you will see "UB-TWS09" listed. Tap this model to select it, the LED will begin to slowly blink blue, and the earbuds will emit a tone to indicate that it has been successfully paired with your device.

- NOTE: If your device asks for a password to connect to the earbuds, enter "0000"**

### Reconnect to Bluetooth

- You only need to pair your Bluetooth device with this earbuds once.
- With your previously paired device's Bluetooth turned on and in range, power on the earbuds, it will automatically reconnect to the last Bluetooth device they were connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select "UB-TWS09" from your list of paired Bluetooth devices.

### Play

- Connect your device to this earbuds via Bluetooth (see "Pair & Connect with a New Device").
- Open your favorite music app and press play.
- Press the "Power" button once to play/pause music & answer/end calls, or press it twice to skip to the next track.
- All audio, including music, games, videos, and notifications will be routed through the Earbuds.

### Power off

- Press and hold power button on left or right earbud for 3-5 seconds, the earbuds will emit a descending tone to indicate that the earbuds are now powering off.

### Troubleshooting

No power	Recharge your earbuds using the included battery charging case.
Music is not playing over bluetooth	Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the earbuds to reconnect your Bluetooth device.
Bluetooth device will not reconnect with the earbuds	Navigate to your Bluetooth settings menu on your Bluetooth device, tap "UB-TWS09", and select "Forget". Now follow the steps to pair your device again.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.