

Battery Information:
 Built-in Battery: Lithium
 Input: DC 5V/1A
 Capacity: 400mAh
 Music playing time: Up to 6 Hours*
 Charging time: 2 hours
 *Approximate playback time. Battery life depends on individual use and may be slightly more or less than the time specified.

Speaker Specifications:
 Output Power: 3W
 Driver Size: 63mm
 Impedance: 4Ω
 Frequency Response: 150Hz-18KHz

Bluetooth® Information:
 Bluetooth® Specification: V2.1
 Operating Distance: 10 Meters (Class II)
 System Requirements: Bluetooth-capable device

Additional Connection Sources:
 Power Source: Built-in rechargeable battery via Micro USB to USB cable
 Audio Input: 3.5mm Input

Technical Support:
 If you are experiencing problems, do not attempt to fix the product yourself or return it to the store you purchased it from. Please refer to the user's manual or just contact our helpful tech support team:

Merkury Innovations
 39 Broadway, 15th Fl
 New York, NY 10006
 www.merkuryinnovations.com
 support@mercuryinnovations.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:
 1. This device may not cause harmful interference.
 2. This device must accept any interference received, including interference that may cause undesired operation.

©2016 Merkur Innovations, LLC. • To explore our full selection of products, please visit www.merkuryinnovations.com. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.
Made in China

Charge It

- Plug the micro USB cable into the micro USB port on the back of the speaker, and connect the other end of the cable with any compatible charger or wall outlet.
- When charging, the LED indicator on the back of the speaker will glow red - when fully charged, the LED indicator will turn off.
- Charging time is approximately 2 hours.

Turn It On/Off

- Switch the power button on the back of the speaker to turn it ON and OFF.
- Switch the power switch to "ON," the speaker will emit a tone and the LED light will turn on.
- Switch the power switch to "OFF," the LED light will turn off.

Pair & Connect with a New Device

- Make sure the speaker is turned off and your device's Bluetooth setting is activated.
- Turn the speaker on; after a few seconds it will automatically enter into pairing mode and the LED will flash.
- On your Bluetooth-enabled device, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices. Wait a few seconds and select "MERKURY SB004". The speaker will emit a tone when successfully paired.

NOTE: If your device's Bluetooth version is below version 2.1, you may need to enter the password "0000".

AUX-IN: The speaker will switch to wired mode automatically once the included 3.5mm AUX cable is inserted into the AUX-IN port.

Play

- Connect your device to the speaker via Bluetooth (see "Pair & Connect with a New Device").
- Open your favorite music app and press play.
- Control the music, track & volume from your device, or control them from the controls on the speaker.
- Press the "P" button once to play/pause music, and to answer/end calls.
- Press the "+" or "-" button once to raise/lower the volume on the speaker. Press and hold to skip to the next/previous track.
- All audio, including music, games, videos, and notifications will be routed through the speaker.


NOTE: Volume levels on your device and on the speaker are controlled separately.

NOTE: On-speaker playback only works over Bluetooth, and will not work when your device is connected via an AUX cable.

Reconnect to Bluetooth

- You only need to pair your Bluetooth device with the speaker once.
- With your previously paired device's Bluetooth turned on and in range, power on the speaker.
- The speaker will automatically reconnect to the last Bluetooth device it was connected to.
- If a previously paired device does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select "MERKURY SB004" from your list of paired Bluetooth devices.

Ports and Features



Troubleshooting

- | | |
|---|--|
| No power | First, recharge your speaker using the included charging cable. Then, try using a different micro USB cable. |
| Music is not playing over Bluetooth | Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Make sure there isn't a 3.5mm cable connected to the AUX input. Restart the speaker to reconnect your Bluetooth device. |
| Bluetooth device will not reconnect with the speaker | Navigate to your Bluetooth settings menu on your Bluetooth device, tap "MERKURY SB004," and select "Forget." Now follow the steps to pair your device again. |

MERKURY
 INNOVATIONS

BLUETOOTH®
 WIRELESS

GIDGET

Bluetooth® Wireless Speaker



User's Manual for KTS-820B

IMPORTANT

Inside Box:
 Bluetooth® Speaker
 Micro USB Charging Cable
 3.5mm Audio Cable
 User Manual

PLEASE READ BEFORE USING THIS PRODUCT

- Features:**
- Automatically reconnects with the last connected Bluetooth® device
 - Rechargeable battery provides up to 6 hours of continuous playback
 - On-board playback & volume controls

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.