


Wireless Earbuds with Charging Case




USER MANUAL


MODEL: BE1030

Please read this manual carefully before using the product
and keep it in a safe place.

PACKING LIST




X1




(Size M is preinstalled on earbuds)



X1



User Manual X1




Quick Guide X1

DIAGRAM



LED light




Type-C charging port



LED Indicator

Touch area




Microphone port

Charging pins


CHARGING

- Remove the protective film from the earbuds when using for the first time.
- Fully charge both earbuds and the charging case before the first-time using.
- To prevent damage, use the provided USB-C cable.
- Fully dry off the earbuds and the USB port before charging.



POWER ON

Mode 1



- Take both earbuds out from the charging case the earbuds will automatically turn on (with white LED lights flashing) and start pairing.


Mode 2



- In the shutdown status and when the earbuds are not in the charging case. Simultaneously click and hold the MFB of both earbuds for 3 seconds to power on and go into pairing mode (with the white LED lights flashing).


POWER OFF

Mode 1



- Put the earbuds back to the charging case to turn them off.


Mode 2



- If the earbuds are not in the charging case. Pause music first, click and hold the MFB of both earbuds for 4 seconds to turn them off.


PAIRING

Mode 1



1. Take both earbuds out from the charging case. They will automatically enter the pairing mode in which the LED lights flash white, and then select "BE1030".

Mode 2



2. If the earbuds are not in the charging case. Click and hold the MFB of both earbuds for 6 seconds. they will automatically enter the pairing mode and then select "BE1030" on your phone.



Note :The earbud will reconnect to the paired device by priority. If you want to pair to the second smartphone. Please disconnect name on the paired smartphone.

TOUCH CONTROL

Volume UP/Down

Volume+: click and hold the MFB button of Left earbud to turn up the volume.

Volume-: click and hold the MFB button of Right earbud to turn down the volume.

Next / Previous Track

Next Track: double click the MFB of Right earbud.

Previous Track: double click the MFB of Left earbud.

Play / Pause

Click the MFB of either earbud once.

Answer / hang up

Click the MFB of either earbud once.

Reject a call

Double click MFB button when there is an incoming call.

Activate Siri

Triple click the MFB button of either earbud

RESET

Click the MFB button of either earbuds 5 times while in pairing mode, the LED lights will flash 3 times that means it has been reset successfully

SPECIFICATION

Earbuds

Wireless version: V 5.1

Working distance: 10M (barrier-free)

Battery: 50mAh

Working time: 4~6 hours

Charging time: 1.5hours

Charging case

Battery: Li-battery 700 mAh (Extra 4 times full charge for earbuds)

Chaging times: 2 hours

Input:5V 1A

Out put: 5V 120mA

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.