


TWIN WIRELESS EARBUDS

WITH CHARGING CASE




USER MANUAL
MODEL: BE1033

Please read this manual carefully before using the product
and keep it in a safe place.

PACKING LIST




X1



(Size M is preinstalled on earbuds)



X1



User manud X1



Quick Guide X1



DIAGRAM



LED light





Type-C charging port



CHARGING

- Remove the protective film from the earbuds when using for the first time.
- Fully charge both the earbuds and the charging case before the first-time using.
- To prevent damage, use the provided Type-C cable.
- Fully dry off the earbuds and the USB port before charging.
- Close fully the charging case cover to charge the earbuds.



POWER ON

Mode 1



- The earbuds will automatically turn on (with blue LED light flashing) and start pairing when you open the charging case.

Mode 2



- In the shutdown status and when the earbuds are not in the charging case. Simultaneously click and hold the MFB of both earbuds for 3 seconds to power on and go into pairing mode (with the blue LED light flashing).

POWER OFF

Mode1



- Put the earbuds back to the charging case and close the case to turn them off.
- Note: Earbuds will not turn off automatically if charging case is out of battery.


Mode2



- If the earbuds are not in the charging case. Pause music first, click and hold the MFB of both earbuds for 4 second to turn them off.


PAIRING

Mode1



1. Open the charging case, they will automatically enter the pairing mode in which the LED light flashes blue, and then select "BE1033".

Mode2



If the earbuds are not in the charging case. Click and hold the MFB button for 6 seconds, they will automatically enter the pairing mode and then select "BE1033" on your phone.



Note : The earbud will reconnect to the paired device by priority. If you want to pair to the second smartphone. Please disconnect wireless on the paired smartphone.

TOUCH CONTROL

Volume UP / Down

Volume+: Click and hold the MFB button of Left earbud to turn up the volume increasingly.

Volume-: Click and hold the MFB button of Right earbud to turn down the volume.

Next / Previous Track

Next Track: Double click the MFB of Right earbud.

Previous Track: Double click the MFB of Left earbud.

Play / Pause

Click the MFB of either earbud once.

Answer / Hang Up

Click the MFB of either earbud once.

Reject

Double click the MFB button of either earbud when there is an incoming call

Activate Siri

Click and hold the MFB button for 2 seconds.

RESET

Delete the connection name in wireless list of your phone. Turn off both earbuds and then triple-click the MFB button of both earbuds, the LED lights flash light blue three times to indicate that the earbuds have been reset successfully.

SPECIFICATION

Earbuds

Wireless version: V 5.0 dual mode

Working distance: 10M (barrier-free)

Battery: 50mAh

Working time: 6 hours (50% volume)

Charging time: 1.5hours

Earpiece weight: 7.6g

Charging case

Battery: Li-battery 650 mAh (Extra 4 times full charge for earbuds)

Chaging times : 2 hou rs

Input: 5V 1A

Out put: 5V 100 mA

Weight: 56.8g

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.