品牌

2021.10.26 V1.0 首次创建

INDICATOR LIGHT GUIDE

Main router: Connected to broadband.
Sub router: Connected to the main router and

Flashing white light

Main router: Connection to broadband is intermittent. Sub router: Connected to the main router but signal is weak. Try moving it closer to the main

Solid amber light

Main router: Ready for configuration. Sub router: Ready to connect to the main

Flashing amber light Sub router: Pairing and syncing with the main

Solid red light

System is starting up. This will take about a minute.

Flashing red light

Main router: Unable to connect to broadband Follow these steps to troubleshoot:

1. Make sure the WAN/LAN port is connected to the modem with an Ethernet cable. 2. Make sure the Ethernet cable is securely

3. Check if the modem's broadband settings are correct. If the Internet access method is DHCP. the router can directly access the Internet. If the Internet access method is PPPoE, make sure you have entered the correct broadband account name and password provided by your

4. Check if your broadband connection is working

Sub router: Unable to connect to the main router. Follow these steps to troubleshoot:

1. Move the sub router closer to the main router. 2. Reset the sub router to factory settings.

3. Make sure you have completed the setup process in the app.

FCC Statement

properly.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Recrient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is

·Consult the dealer or an experienced radio/TV

technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this could not be a supported by the could be a supported by the cau

equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

ISED Statement

This device contains licence-exempt transmit-ter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:


(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

nis device meets the exemption from the outine evaluation limits in section 2.5 of RSS 102 and ompliance with RSS 102 RF exposure,users can obtain Canac information on RFexposure and compliance.
This equipment complies with Canada radiationexposure limits set forth for an uncontrolledenvironment.
This equipment should be installed and operatedwith minimum distance 20cm between theradiator & your body, cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la onformité.Cet équipement est conforme aux limites d'exp aux rayonnements du Canadaétablies pour un environr non contrôlé.Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre leradiateur et votre corps The device for operation in the band 5150 - 5250 MHz is only findoor use to reduce the potentialfor harmful interference to co-channel mobile satellite systems.

L'appareil destiné à fonctionner dans la bande 5150-5250 MHz est uniquement destiné à uneutilisation en intérieur afin de réduire le potentiel d'interférences nuisibles aux systèmes mobilespar satellite cocanaux.



型号:VL6WF02

规格:VL6WF02-KSZP01 V2.0

物料编码:

UPC:

Scale 1:1 Unit:mm 字体: Montserrat light

样品 物料材质 ▶ 105g无光铜 审核▶ 产品名 ▶ Vilo6 Mesh Wi-Fi System 说明书 (美版) 印刷颜色 ▶ CMYK 样品数量 ▶ 设计于 ▶ 曹佳丽 批准▶ 成品尺寸 ▶ 60*100mm 特种工艺 ▶ 风琴折