

SAFETY PRECAUTION:

* Keep the product, accessories and packaging parts out of reach of children to prevent accidents and of a charge seep the product for to avoid corrosion.

**Do not expose the product to extreme temperatures below -10°C (5°F) or above 50°C (131°F), to main lifespan of keyboard or battery.

PECIFICATIONS.
Number of Keys. 78 (Mechanical Switch)
Minber of Keys. 78 (Mechanical Switch)
Main Body Material: PC
Main Body Material: PC
Battery. 4.000mAh Li-ion Rechargeable Battery
Bluetooth Working Time (Backlit 70%): Around 2 weeks (Single Charge)
Bluetooth Working Time (Backlit 70%): Around 2 weeks (Single Charge)
Charging Time: Around 5 hrs (USB 3.0)
Charging Port. Micro USB
Bluetooth Operating Distance: Up to 10m (Open Space)
Bluetooth Operating Distance: Up to 10m (Open

OVERVIEW:

1. LED INDICATOR:
2. OS TOGGIES SWITCH:
3. MODE SWITCHING:
4. MICRO USE PORT
Charging Indicator: Battery less than 20%,
LED blinks rapidly, Charging, LED blinks slowly;
Fully charged, LED remains bright.





CHARGING

CHARGING

When battery is less than 20%, the LED indicator near Micro USB port will blink rapidly. Plug the USB cable into a USB port and plug her other end into the port in the key-board. The LED indicator will blink slowly while charging. Once fully charged, the LED indicator remains bright (this takes around 5 hours).

The lofree keyboard is compatible with all USB ports. For the best signal and fastest charging time, please use USB 3.0. The product can be charged under Bluetootty/On/Off Mode.

BLUETOOTH/WIRED MODE (TOGGLE SWITCH)
WIRED MODE
1. Switch the keyboard to ON position.
2. Connect our USB cable withy our PC and keyboard.
"Under Wired Mode, keyboard will not enter into Battery Saver Mode.

ELIMINE Wired Mode, keyboard will not enter into Battery saver-move.

BUETOTH MODE

1. which the keyboard to Bluetooth position.
2. Long press combination key "fin-1" for 3 seconds to activate Bluetooth pairing (the Caps Lock light indicator blinks).
3. Search Bluetooth device "DOT@LOFREE" on your device, and connect it (light indicator goes off after pairing successful).
3. Search Bluetooth device "DOT@LOFREE" on your device, and connect it (light indicator goes off after pairing successful).
5. Search Bluetooth device "OT@LOFREE" on your device, and connect it (light indicator goes off after pairing successful).
5. Search Bluetooth device "fin-2" / "fin-3" for switch, and follow the above procedures to connect with other devices.
5. Stow or failed connections may exists due to different Bluetooth versions, please make sure all the settings are correct.
5.WITCH BLUETOOTH DEVICES.
5. SHORT press combination key "fin-1" / "fin-2" / "fin-3" to switch to other device.

TURN OFF KEYBOARD Switch to OFF position.

BATTERY SAVER
Under Bluetooth mode, keyboard backlit goes off when it is inactive after 5 minutes. After 10 minutes of inactivity, the keyboard enters into sleep mode. Click any button to wake the keyboard.

OS SWITCH
1--MAC/IOS
1-mthe switch to Mac/IOS when you are connected to a Mac or IOS operating system. The multimedia keys on the
keyboard are activated. Using the F1-F12 functions can be used by pressing "fn" simultaneously.
2--WINDOWS/ANDROID
1--WINDOWS/ANDROID
1--WINDOWS/ANDR

when using the Windows/Android mode, the button, which is on the left side of the space bar is functions as a button. And the button on the right side of the space bar functions as a button. And the button on the right side of the space bar functions as a button. NOTE: Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS. We also recommend not to switching OS frequently as it may impact operation of the keyboard.

MULTIMEDIA FUNCTION

MULTIMEDIA FUNCTION

MULTIMEDIA FUNCTION

FU

TROUBLESHOOTING

I can't pair the keyboard with my device.

Lan't pair the keyboard with my device.

Restart the device and try pairing it with the keyboard again.

Note: On a Windows computer, a new Bluetooth connection will sometimes require additional software updates—a process that may still be ongoing after a message appears indicating a successful completion. Wait at least 20 minutes after pairing to make sure all updates are completed before restarting the computer.

Confirm that the device is configured to accept Bluetooth connections (Windows) and supports an external keyboard (tilt) profile).

Go to Bluetooth Devices > Open Settings and select the following checkbox:

Allow Bluetooth devices to find this computer

Alert me when a Bluetooth device wants to connect

My keyboard ian't working.
Tum the keyboard of and back on.
Tum the keyboard of and back on.
Tum the keyboard of and resiant the computer, (Windows)
On the device.
Go to Bluetooth settings and turn off Bluetooth and "forget" the keyboard.
Restart the device and turn on Bluetooth to reconnect.

Bluetooth connection is interrupted within 10 meter.
Check if the keyboard is resting on a metal surface that can interfere with the Bluetooth signal.

Third parties input tools does not compatible with the keyboard.

Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third parties input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

Certain fn keys or multimedia keys does not working under Windows/Android mode. Functions of certain multimedia key may be disabled due to compatibility, versions, brands and drivers of Windows/Android OS.



Shenzhen Lofree Culture Co., Ltd.
http://lofree.co
hello@lofree.co
Find us on:

#@lofree.co
O@lofree.co
Designed by Shawn@lofree
Assembled in China

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.