

DETAILED OPERATION

Charging

- When the battery is less than 20%, the battery indicator breathes red. Please use the attached Type-C cable to charge.
- During the charging process, the power indicator is white and often breathing in the fully charged state, the battery indicator is steady white.




Note: The Type-C cable can be plugged into the USB interface of the computer to complete the charging (the product can be charged under Bluetooth/wired/Loff state)

Wired/Bluetooth /2.4G Usage


Wired Mode

- Turn the mode switch to CAB.
- Take out the Type-C data cable attached and connect the keyboard to the device to complete the wired connection mode.



Bluetooth Mode:

- Turn the mode switch to WLS.
- Long press Fn+F1/Fn+F3, the Bluetooth indicator blinks slowly.
- Turn on Bluetooth function for your device, find and click "DOT 2@Lofree" in the Bluetooth device list.
- If the Bluetooth indicator is steady on, the Bluetooth connection is successful.




Note: MAC system devices do not support multimedia functions in 2.4G connection mode.

System Switch

- Mac/iOS: Turn the system switch to the Mac/iOS, which matches the usage habits. The multimedia keys on the keyboard are activated. Using the F4/F5 functions can be used by pressing "Fn" simultaneously.
- Windows/Android: Turn the system Switch to the Windows/Android, which matches the usage habits. The F4/F5 keys are activated. If you want to use the multimedia keys, press "Fn" simultaneously.

2.4G Connection Mode:

- Turn the mode switch to WLS.
- Remove the 2.4G receiver from keyboard.
- Plug the 2.4G receiver into the USB port of the device.
- If press Fn+F4, then 2.4G indicator blinks slowly to steady on, the connection is successful.



Note: MAC system devices do not support multimedia functions in 2.4G connection mode.


System Switch

- Mac/iOS: Turn the system switch to the Mac/iOS, which matches the usage habits. The multimedia keys on the keyboard are activated. Using the F4/F5 functions can be used by pressing "Fn" simultaneously.
- Windows/Android: Turn the system Switch to the Windows/Android, which matches the usage habits. The F4/F5 keys are activated. If you want to use the multimedia keys, press "Fn" simultaneously.

Light Effect

Light Modes:


- Press Fn+Up arrow key, light effect mode 1 → light effect mode 2 → light effect mode 3.
- Press Fn+Down arrow key, light effect mode 2 → light effect mode 1 → light effect mode 3.



Note: There are 4 kinds of frequency.

Light Brightness


- Short Press Fn+F5 to dim the brightness.
- Short Press Fn+F6 to turn up the brightness.



Note: There are 4 levels of brightness: 0%, 40%, 70%, 100%.

Light Frequency

- Press the Fn+Left arrow key to slowdown the frequency.
- Press the Fn+Right arrow key to slowdown the frequency.



Note: There are 4 kinds of frequency.

Multimedia Combination Function Key

Multimedia sign	Mac	Windows
Esc	Winkey Lock	Winkey Lock
F1	Screen BR-	Screen BR-
F2	Screen BR+	Screen BR+
F3	Multi-Screen	Multi-Screen
F4	Search	Search
F5	Backlit-	Backlit-
F6	Backlit+	Backlit+
F7	Prev Song	Prev Song
F8	Pause	Pause
F9	Next Song	Next Song
F10	Mute	Mute
F11	Vol-	Vol-
F12	Vol+	Vol+
Fn+PrntSc	/	Calculator
Fn+Del	Ins	Ins
Fn+Ctrl	Menu	Menu

NAME AND CONTENT OF HAZARDOUS SUBSTANCES IN PRODUCT:

Hazardous Elements	Hazardous Substances						
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium (Cr)	Polychlorinated Biphenyls (PCB)	Polycyclic Aromatic Hydrocarbons (PAH)	Phthalates
RoHS Compliance	0	0	0	0	0	0	0
RoHS Part B Compliance	0	0	0	0	0	0	0
RoHS Part C Compliance	0	0	0	0	0	0	0
RoHS Part D Compliance	0	0	0	0	0	0	0

This table is prepared in accordance with the provisions of SJ/T 11364.

The classification and marking of this product was performed in accordance with the EU directive 2011/65/EU and the revised directive 2015/863/EU.

0-Indicates that the said hazardous substance contained in all the homogeneous materials for this component is below the limit requirement in GB/T 26572.

X-Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

ENVIRONMENTAL PROTECTION INSTRUCTIONS:

The hazardous substances contained in the electronic parts of this product will not leak or change their physical and chemical properties for a period of ten years. During this period, the electronic components of this product will not cause serious environmental pollution or serious damage to human health or property while the products are being used by the consumer.

According to the Chinese electronic industry standard SJ/T 11364-2014 and related Chinese government regulations, this product and some of its internal or external components may have an environmentally friendly use period mark, depending on the component and component manufacturer, the mark lifespan on the product and its components may vary. The expiration date on the component takes precedence over any conflicted or different UL/UP label on the product.

Warning

All of the battery is not replaced properly, there may be leakage or explosion and personal injury hazards.

- Do not use the battery when there is leakage, discoloration, deformation, or any other abnormality.
- Do not leave the battery in a discharged or unused state for a long time.
- Do not short-circuit the product.
- Battery life varies with usage. Used batteries should be disposed of in accordance with local laws or thrown away in trash cans for recycling electronic devices.
- If any liquid accidentally enters the product, please immediately disconnect the power supply and remove the product. Continue to use the product may cause fire or electric shock. Please contact the agent or the nearest customer service center for inspection and maintenance.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and

receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

DOT

圆点三模机械键盘

OE914 DOT Triple Mode Mechanical Keyboard

Lofree

深圳市洛斐客文化有限公司
Shenzhen Lofree Culture Co., Ltd.
深圳市福田区华强北路1005号F518F和创园B座103-104
NO.103-104/F8 Building, F518/DEA Lane, Baoyuan Road, Xixiang
Baoan District, Shenzhen, China.

Service hotline(服务热线): 4000002063
www.lofree.com.cn www.lofree.co

lofree.co lofreeco lofree.co

纸张: 80 g 书写纸