

# Wireless Power Failure Sensor With Alarm


## Model 762T

### HOW IT WORKS


This sensor for detected power failure, when the room or living area power shut off, it will activates 30 seconds alert and sending wireless RF signal trigger compatible receiver unit.

### OPERATION

1. Use a screwdriver to remove the battery cover , Install 3 pcs "AAA" type batteries (Not included) in the battery door, make sure in correct polarity(Fig.1).
2. Plug the AC adaptor to the DC 6V adaptor (Included), The RED indicator will be light on, Install the unit on the area which you want to protected(Fig.2).



(Fig.1)



(Fig.2)

3. Learning ID code to main unit
  - a. The wireless power failure sensor sensor output RF signal compatible trigger auto dialer (T015S, T016S, T055S, T056S, T018S, T058S, T068S) and wireless outdoor siren (526L, 526F, 527SL) and wireless alarm receiver(625RX) function, must learn ID code to main unit then use. learn ID operation: First make auto dialer or wireless siren enter learning mode (refer the their own manual), then turn switch to Sound OFF and pull out adaptor jack from power failure sensor, you will hear the sound of telling you learn ID code successfully.
  - b. After select a location, you should test the sensor transmitting range before mount it permanently, turn local power switch to Sound OFF, turn the Chime switch to ON of T015S, T016S main unit or press HOME button of T055S, T056S, T018S, T068S, after 60 seconds, then pull out adaptor jack from power failure sensor,, you will hear the main unit sounds "DING DONG" chime if signal is received successfully, if not , change location is required.
4. set the function switch to Sound ON, Sound OFF or Power OFF
  - Sound ON - When AC power cutting off or adaptor jack pull out from power failure sensor, will sending wireless RF trigger signal and activates 30 seconds "Bi.Bi.Bi" alert sound
  - Sound OFF - When AC power cutting off or adaptor jack pull out from power failure sensor, will sending wireless RF trigger signal
  - Power OFF - Turn power off
5. When the battery power lower, the unit will "di-di" sound to remind the user replace the new batteries.

**NOTE:** The unit must be plug the AC adaptor, otherwise it will not alarm at any way.

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment