

Product: DrumBass Explore<sup>BT</sup> Bluetooth Speaker

Model: FG-8030N

### **User Guide**

Thank you for purchasing a Lifetrons® DrumBass Explore<sup>BT</sup> Bluetooth Speaker. This pocket-sized speaker features revolutionary portable audio technology with built-in bass support and Bluetooth for wireless music. The DrumBass Explore<sup>BT</sup> Bluetooth Speakers is equipped with a high-fidelity speaker to ensure smooth delivery of mid and high-range tones. It comes with a built-in rechargeable battery for easy use.

This guide outlines the operating procedures and safety precautions. Please read it carefully to make sure you are using your product properly and retain it for future reference.

### **What's Included**

- DrumBass Explore<sup>BT</sup> Bluetooth Speakers
- Audio cable
- Micro-USB charging cable
- Storage pouch
- User guide

### **Compatibility**

- Any portable audio device with Bluetooth capability
- Any device with a 3.5mm input for audio playback
- Any USB port for charging

**Please note:** The USB port only supports the charging function; it is not able to function as a USB audio speaker.

### **Features**

- Built-in Bluetooth® 4.0 wireless technology works up to 10 meters
- Enjoy up to 9-12 hours of audio playback time
- Easily control the volume or choose songs wirelessly
- Dual color LED display indicates charging or playback status
- Exclusive carrying case protects the speaker when not in use

### **Specifications**

- Wireless range: 10m
- Output: 5W
- Charging time: 3 hours


- Music playback time: up to 9 - 12 hours
- Rechargeable via standard USB output

## How to Use


### A. How to Recharge

1. Connect part ① (micro-USB jack) to ② (micro-USB port).
2. Connect ④ (USB plug) to a USB port with a power supply (i.e. computer USB port or AC adapter with USB power supply).

### B. How to Connect to a Music Player using an Audio Cable

1. Connect part ③ (3.5mm audio jack) directly to any music player with a 3.5mm audio jack or mobile phone via the audio connector (not included).
2. Connect the other end of the audio cable to part ⑤ (3.5mm audio input) of the speaker.
3. Turn the power switch to  (located Back of the speaker) to experience the stunning sound.

### C. How to Connect to a Music Player using Bluetooth

1. Turn on the connecting device (music player/computer) you want to pair the speaker with.
2. Turn on the Bluetooth function on the connecting device (music player/computer).
3. Turn the power switch to  (located back of the speaker), it will start searching for a connecting device and the LED indicator will quickly flash the color blue.
4. Once the speakers and the device are paired, the connecting device will prompt you to select the paired component. Select "FG8018 Lifetrans" from the list of Bluetooth-enabled devices shown on your device.
5. If asked for an input passkey, input the number "0000" (This is the default passkey for the majority of Bluetooth devices). Press "OK" to complete the pairing process.
6. Once pairing is complete there will be a prompt tone and the LED indicator on the speaker will keep flashing slowly.

## LED Battery Indicator

### When Charging:

Red flickering light – Charging  
White light on – Fully charged

### When in Use:

White light on – On  
Red light on – Low battery

## FAQ's

### 1. Why isn't there any sound even though the speaker is turned on?

Please make sure that the battery has been charged for at least 4 hours. The red LED will be flashing when charging. For optimal performance, please set the volume level of your MP3 to 60-70%.

### 2. Why isn't there any sound when I connect the speaker to my music player?

Case 1: When you connect the 3.5mm audio cable to your speaker, make sure that the speaker is switched to the cable function and that music is playing on your music player. Check if the volume is adjusted too low. See if the 3.5mm audio jack is properly connected. Keep in mind that the speaker is not a USB audio device; it does not play music via USB connection. The USB plug is for charging only.

Case 2: When you connect your speaker using Bluetooth, make sure your music player's Bluetooth is turned on, the speaker is switched to the Bluetooth function and that music is playing on your music player. Check if the volume is adjusted too low. Check if the speaker and your device are paired properly, once pairing is complete there will be a prompt tone and the LED indicator on the speaker will keep flashing slowly.

### 3. Is this a USB audio device?

No, this is not a USB audio device. The USB plug is for charging purposes only. To play music, connect the 3.5mm audio jack to any music player.

### 4. How can I tell if the speaker has been fully charged?

When the indicator LED changes from flashing red to solid white, the speaker has been fully charged.

## Safety Precautions

Please follow the rules outlined in this guide closely to ensure your safety and flawless operation:

- Be cautious of any edges, uneven surfaces, metal parts, accessories or packaging to prevent possible injury or damage. Take note that this product should not be placed in your mouth.
- Do not modify, repair or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. and will void the warranty.
- Do not use any kind of liquid to clean the product. Keep in mind that the surface of the product should only be wiped with a clean dry cloth.
- Do not use this product in locations with high temperatures or high humidity levels (i.e.: bathrooms); ideally, the product should be used in a location free of excessive dust and not exposed to direct sunlight.
- Do not insert foreign objects or liquids into the product; this could damage the product.
- Do not touch this product when your hands are wet; this could result in electric shock.
- Refrain from dropping the product or bumping it against other objects.

- Do not use this product in hazardous locations.
- Should any abnormal situations or problems occur while using this product, discontinue its use immediately.
- The product may explode if disposed of in a fire.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### **Battery**

Although fully charged and ready for use, it is recommended that you completely use the initial charge up, then recharge the product at least two more times to ensure the best possible performance.

### **Children**

Keep out of reach of children. Do not allow children to play with your product or its accessories. They could hurt themselves or others and could accidentally damage the product. Your product and its accessories may contain small parts that could become detached and create a choking hazard.

### **Disposal of Electrical and Electronic Equipment**

This symbol indicates that all electrical and electronic equipment included with this product should not be treated as household waste. Instead, it should be left at the appropriate collection point for the recycling of electronic equipment. By ensuring this

product is disposed of correctly, you are helping to prevent negative consequences for the environment and human health. To recycle this product, please contact your local city office, household waste disposal service or where you purchased the product.

### **Limited Warranty**

If within 12 months of purchase this product or any part thereof is proven to be defective by reason of faulty workmanship or defect in materials, we will repair or replace the same product free of charge of labor or materials on condition that:

1. The original invoice or sales receipt with the date of purchase is presented with the defective unit.
2. Lifetrans does not take any responsibility for lost information of any kind and will not reimburse you for any such loss.
3. The limited warranty is only valid if the original proof of purchase for this product, issued by a Lifetrans authorized dealer, specifying the date of purchase, is presented with the product to be repaired or replaced. Lifetrans reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the product from the dealer.
4. A rechargeable battery can be charged and discharged over one hundred times. However, it will eventually wear out - this is not a defect and corresponds to normal wear and tear. When the playback-time or standby time is noticeably shorter, it is time to replace your battery. Please do not make repairs, modifications, or installations without contacting an authorized Lifetrans representative.
5. The warranty does not cover product failures which have been caused by use of accessories or other peripheral devices which are not Lifetrans branded original accessories intended for use with the product. The warranty does not cover any damage caused by misuse, abuse, neglect or accidental breakage.
6. The warranty does not cover product failures caused by modifications, repairs or disassembly by any person not authorized by the manufacturer.
7. Any defective unit or part shall become property of the manufacturer.

### **Additional Information**

Please register your Lifetrans product online at **[www.lifetrans.com](http://www.lifetrans.com)**.

Please visit our website **[www.lifetrans.com](http://www.lifetrans.com)** or contact our customer service center at **[cs@lifetrans.com](mailto:cs@lifetrans.com)** to learn more about our new products and special offers.

©Copyright 2015 by Lifetrans Switzerland AG. Lifetrans® is a registered trademark of Lifetrans Switzerland AG or Lifetrans International Limited. All brands and product names listed are trademarks or registered trademarks of their respective holders and are hereby recognized as such. Specifications are subject to be changed without prior notice. All rights reserved.

This user guide was originally composed in English and was subsequently translated into other languages. The fidelity of subsequent translations cannot be guaranteed. In case of conflict between the English version and another language version, the English version takes precedence.