

720P WIRELESS DIGITAL SECURITY CAMERA SYSTEM

LWU3620-C QUICK START GUIDE

Getting Started



This system comes with the following components:

4x wireless 720p indoor/outdoor cameras*
4x antennas for cameras (pre-attached)*
4x power adapters for cameras*4x mounting kits for cameras*

1x wireless indoor/outdoor receiver
2x antennas for receiver (pre-attached)
1x mounting kit for receiver
1x double-sided tape for receiver

*Quantity only applies to the LWU3624.
The LWU3622 contains 2 units of each.


NOTE: The LWU3624/LWU3622 is only compatible with the LH050.

Installation Tips

- Before you permanently install your cameras:
 - Plan where and how they will be positioned.
 - Determine where you will route the cable that connects the camera to the power adapter.
 - Verify the camera's performance by observing the image on a monitor when the camera is positioned where it will be permanently installed.
 - Avoid installing cameras in locations that require the wireless signal to pass through cement, concrete and metal structures. This will reduce the transmission range.

A. Installing the Cameras

- 1 Mount the camera to the wall or ceiling using the included screws.




Cable Notch

NOTE:

If you run the cables along the wall / ceiling, you must run the cable through the cable notch on the back. This will keep the camera base flush to the wall / ceiling when mounted.

! For outdoor use, installation in a sheltered location is recommended.

- 2 Adjust the angle of the camera until the desired view is set. Tighten the thumbscrew and the adjustment rings to secure the camera position.



A) Turn the adjustment ring to tighten / loosen the stand connection. Adjust the camera's horizontal position.



B) Loosen lower screw with the Allen key to adjust the camera's vertical position.



C) Loosen upper screw with the Allen key to rotate the camera housing.

- 3 Connect the camera power adapter to the camera. Connect power adapter to a power outlet.



NOTE: Power cables are only weatherproof when fully inserted at the connection point. Power cables are not to be submerged in water. Camera extension cables are available on www.lorextechnology.com.

B. Installing the Receiver


- 1 **OPTIONAL** Use the included double-sided tape to securely attach the receiver to a flat surface.

OR

Use the included screws to mount the receiver to a wall.

ATTENTION: Make sure to first connect and power on the cameras before powering on the receiver. This will ensure a proper connection.

- 2 Plug the USB cable from the wireless receiver into your DVR.



NOTE: It is not recommended to install more than 4 digital wireless security cameras in the same environment to maintain optimal video frame rate performance.

Need to extend the wireless range?
Visit www.lorextechnology.com
for further details.

FOR SUPPORT AND INFORMATION,
VISIT WWW.LOREXTECHNOLOGY.COM



www.lorextechnology.com

LWU3624_LWU3622_QSG_EN_R1

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

IC warning

IC warning

- English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and*
 - (2) this device must accept any interference, including interference that may cause undesired operation of the device.*
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

- French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et*
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."*