Accessing Data

WiFi and Mobile Device:
1. Turn on LucidCam WiFi by pressing the WiFi key.

   *WiFi LED will blink when on.
2. Download the LucidApp to your iPhone or Android device.
3. Tap the logo in the bottom navigation bar in the app.
4. Follow directions for device pairing on the next page.

Wired Data Transfer:
Data can also be accessed via the cable included. Connect your LucidCam to a computer to view and share pictures and videos.

Resetting LucidCam

Use a pin or paperclip and hold the reset button for 2 - 3 seconds to clear internal storage and revert any LucidApp updates.

Updating LucidCam

Check the LucidApp for periodic updates.

Charging the Battery

1. Open the bottom cover.
2. Charge your LucidCam with the cable included. While charging, the Power LED will turn orange.
3. Once fully charged, the Power LED will turn green. Disconnect your LucidCam from the cable.
4. Close the cover.

   * Battery life is over 90 minutes with continuous video usage, and over 40 hours on standby.

Viewing Live

Connect any monitor to the micro HDMI port (cable not included) to view live through the LucidCam lenses.

Storing Data

LucidCam has 32GB of internal storage.

   * Usage of a MicroSD card (not included) is recommended.

Storage LED will blink as available storage decreases.

LucidCam

Virtual Reality in Your Pocket

Copyright © 2016 LucidVR

Quick Start Guide

LucidCam Layout

Capture Key · WiFi Key · Mode Switch · LED Indicators

Lenses

Microphones

Micro SD · Reset · Mount · Micro USB · Micro HDMI

First Time Start Up

1. Switch to either Picture or Video Mode to turn on your LucidCam.
2. Wait for the LEDs to blink twice for to indicate first time boot up.
3. Turn off your LucidCam when not in use.

How to use LucidCam

To Take Photos:
1. Slide the switch to Picture Mode.
2. Point your LucidCam.
3. Press the Capture Key to take a picture.

To Take Videos:
1. Slide the switch to Video Mode.
2. Point your LucidCam.
3. Press the Capture Key to begin recording.

   * Record LED blinks when recording.
4. Press Capture Key again to stop recording.

To Turn Off:
Slide the switch to center position.

Pairing and Unpairing LucidCam

Pair your LucidCam to your iPhone or Android device to access and share your photos and videos

1. Turn on your LucidCam.
2. Press the WiFi key to turn on WiFi.

   * WiFi LED blinks when ready to pair.
3. Open the WiFi settings on your phone.
4. Look for an SSID printed at the base of your LucidCam.
5. Search for the corresponding SSID in your phone's WiFi settings.
6. Use the last eight digits of the SSID as the password to complete pairing.

   * WiFi LED stops blinking and remains on when paired.

Unpair your LucidCam from your phone through the LucidApp, or by pressing the WiFi key to turn off WiFi.

   * Turning off WiFi will preserve battery life.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.   These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.   However, there is no guarantee that interference will not occur in a particular installation.   If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that
  to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:
The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.