


Components

- A. ebeamBLE Dongle
- B. User Manual (With Warranty)



USB Connector

Bluetooth LED



User Manual

Component Description.

1. Bluetooth LED (Blue)
2. USB Connector

Product Usage

1. Install "eBeam Scrapbook" (SW Application) on the PC you want to use.
2. Connect eBeam BLE Dongle to PC.
3. Attempt to connect the e Beam BLE Dongle and pre-paired e Beam Sensor by turning on the product.
4. If the Bluetooth LED stops blinking and continues to come in, the connection is complete.

5. Open the eBeamSrcapbook and use the product..

Caution

1. Please use other wireless devices such as Wifi router within Dongle 1M.

(Interference may cause communication failure.)

2. Please, Do not use a USB port that is within 2Cm of HDMI and use a different port.

(Wireless interference may occur depending on the performance of the HDMI cable.)

Warranty

ebeam BLE Dongle 1-year limited warranty summary

ebeam BLE Dongle warrants against defects in materials and workmanship the hardware products and accessories included for one year from the original date of purchase. ebeam BLE Dongle does not warrant normal wear or damage due to accidental or abuse. Please contact your local ebeam BLE Dongle distributor to receive the service or visit ebeam direct retailer or ebeam authorized service provider. Available service options may vary depending on the country in which you are requesting service. Telephone charges and international shipping charges may occur. Please visit www.myebeam.com for complete terms and details of using the service. You can receive a copy of the warranty by email. Warranty benefits apply in addition to the rights provided by local consumer law.

warning

- Do not expose to direct sunlight, fire or other heating devices that produce excessive heat.
- When cleaning the product, wipe it with a dry cloth.
- Please keep in good use of the product.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation