


Quick Start Guide




CHARACTERISTICS

- GPS (Global Positioning System)
- **GPRS Communication**
- Bluetooth
- FM transmitter with car charger antenna
- Loud speaker
- Microphone
- 3D Accelerometer
- Micro SD card connector

GENERAL VIEW





TECH. SPECIFICATION

Performance	Processor Arm11 - 500MHz
	Flash 4GB - RAM 128 MB
	3.5" LCD TFT 320x480 Resistive TP
Power input voltage	5V DC – 2A max
GSM Frequency bandwidth	850/1900
Working temperature	-20°C / 60°C
Internal battery	1000mAh
Dimensions/Weight	100 x 63 x 14 mm / 110g

INSTALLATION

- 1. Using the Alcohol wet wipe to clean the console where you can to paste the magnet support.
- 2. Pasting the 3M side of magnet support on the cleaned console and pushing it strongly.
- 3. Do not touch the magnet during 5h, so it can be fixed very tightly.
- 4. Putting the MUNIC on the magnet support.
- 5. Connecting the associated car charger for FM transmitter

NOTE. The FM transmitter only can work with associated car charger. This FM function should be disabling with other car charger.

USAGE

- 1. With internal battery power supply, the LED power indication button is turned on after 15 seconds and MUNIC is self-checking.
- 2. For first switch on MUNIC, you need to answer a few questions to set up it by tapping the screen. The device may need a few minutes to determine
- 3. To planning a route, you just need tap "Navigate to" and enter the address. For your security, you should plan the route before driving.
- 4. To get the voice guiding or make phone call by MUNIC, you need to tap the screen and active the loud speaker, the micro will be active
- 5. To play spoken instructions or music through a Bluetooth device and FM transmitter, you have to connect the associated car charger then active the Bluetooth and FM transmitter, at the same time turn on the radio of your car. Once your radio finds MUNIC and the Bluetooth connection is established, the sound will be played through the radio on your car.
- 6. Changing between day color and night color can be automatic, or by tapping the menu.
- 7. To turn off the devices, push the power button for 15 seconds and confirm by tapping the screen.

For customers in the United States

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Caution

Exposure to radio frequency radiation

To comply with FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or

Please note the FM only can work with associated car charger. This FM function will be disable with other car charger.

Caution: Any changes or modifications made on the system not expressly approved by the manufacturer could void the user's authority to operate the equipment.

RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

RF Exposure Requirements: 47CFR§1.1307(b)

RF Radiation Exposure Limits: 47CFR§1.1310

RF Radiation Exposure Guidelines: 47CFR§2.1091