


CONTROLLER OPERATION FONCTIONNEMENT DU CONTRÔLEUR



POWER BUTTON
Turns the LEDs ON and OFF.

BOUTON D'ALIMENTATION
Allume (ON) et éteint (OFF) les DEL.



SAVE COLOR
Choose a button from 1 to 5 to store the desired color.

SAUVER LA COULEUR
Choisir un bouton de 1 à 5 pour sauvegarder la couleur désirée.



DEFAULT COLORS
Choose a color with a single push of a button.

COULEURS PAR DÉFAUT
Choisir une couleur avec en appuyant simplement sur un bouton.



DIM FEATURE
Press to gradually dim the lights.

FONCTION GRADATEUR
Appuyer pour baisser graduellement les lumières.



START SCAN
Scan through 50 colors, each color will stay on for 2 seconds.

LANCER LE BALAYAGE
Passe à travers les 50 couleurs, chaque couleur restera affichée pendant 2 secondes.



FADE MULTI-CHANGER
Changes color at a fast or slow speed.

MULTI-CHANGEUR FONDU
Change de couleur à une vitesse rapide ou lente.



STOP SCAN
This button will stop the scanning at the desired color.

ARRÊTER LA RECHERCHE
Ce bouton arrêtera le défilement des couleurs à la couleur désirée.



STROBE MULTI-CHANGER
Changes color at a fast or slow speed.

STROBOSCOPIQUE MULTI-CHANGEUR
Change de couleur à une vitesse rapide ou lente.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.