


Please follow these instructions regarding NiCd vehicle battery charging and safety. Use charger only under adult supervision.

BATTERY CHARGING/CARE - 9.6V TURBO™ BATTERY

1. Plug wall pack charger into standard 110/120 volt outlet.
2. Connect the wires leading from the battery pack to the wall pack charger connector. Make certain the two connectors are tightly snapped together.
3. To disconnect wires, push down on the connector clip and pull apart.
4. Your battery pack consists of new parts and materials; therefore, you should charge the battery pack for 5 1/2 hours the first two times you charge the battery. Subsequent charges will require only 4 hours.
5. After charging for 4 hours, the battery will feel warm. This condition is normal for fully charged batteries.
6. Charging the battery pack for more than 4 hours will not give you a longer running time. 4 hours is all that is required for a fully charged battery pack.
7. Unlike alkaline batteries, where the power loss is gradual, a NiCd (nickel-cadmium) battery will run for its normal running time, depending on your particular vehicle, and then lose most of its power at once. It is time to recharge the battery pack. Running time will vary, depending upon which R/C vehicle you have.
8. After use, the battery pack will be hot! Wait at least 20 minutes until the battery pack cools before recharging. Recharging a warm or hot battery pack will greatly reduce the number of times your battery pack can be recharged.



THIS PRODUCT USES A NICKEL-CADMIUM RECHARGEABLE BATTERY PACK. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY. FOR FURTHER INFORMATION REGARDING BATTERIES OR THEIR DISPOSAL PLEASE CALL 1-888-557-TYCO.




CONTENTS

- Vehicle
- Transmitter
- 9.6V NiCd Battery Pack, 9.6V NiCd Charger
- 9V Battery

BOTTOM VIEW

Steering Adjuster (adjust, if necessary, to keep vehicle running straight)




Battery Door Latch

VEHICLE OPERATION

- FORWARD
- REVERSE
- LEFT
- RIGHT

TOP VIEW

On/Off Switch



Gear Selector (low/high)

Refer to label on transmitter and vehicle for frequency. Do not race vehicles with the same frequency.

CAUTION-ELECTRIC TOY NOT TO BE RECHARGED IN PLAYS OR ARE AS WITH ALL ELECTRIC PRODUCTS, CHILDREN SHOULD BE SUPERVISED DURING HANDLING AND USE TO PREVENT ELECTRICAL SHOCK. INQUIRY: TYCO, 11000 W. 100th, WYOMING, WY 83091, U.S.A.

TYCO R/C SUPPORT REGISTER YOUR VEHICLE 2 WAYS!
Online...or toll-free!

tyco.com

1-888-557-TYCO (8926)

If you have questions or problems with your vehicle, **DON'T RETURN IT TO THE STORE!**... get help from the EXPERTS! Just click or call.



Keep these instructions for future reference. They contain important information. **IMPORTANT:** Please read all "Owner Information" (last page) before operating your vehicle.

CAUTION: Surfaces may become hot and cause burns if electronics get wet. Do not operate vehicle through water or snow.

POWER SYSTEMS


Your vehicle requires a 9.6V NiCd battery pack and charger. For detailed information regarding battery charging and safety, please follow the specific instructions in this manual.

VEHICLE BATTERY INSTALLATION

1. Rotate battery latch to open position. Open battery door.
2. Insert battery pack into battery compartment as shown.
3. Plug wire connector securely into battery compartment as shown.
4. Close battery door. Rotate battery latch to locked position.
5. To remove battery pack, turn latch, open battery door, unplug wire connector and lift battery out.





The battery door is designed to be removable. If it comes off the hinges, simply reattach it.



TRANSMITTER BATTERY INSTALLATION

1. To install transmitter battery, open battery door as shown.
2. Install one 9V battery with polarity (+/-) as shown inside battery compartment.
3. Push the battery door forward and snap shut.



CONSUMER INFORMATION:

IMPORTANT: Please read before operating your vehicle.

SAFETY INFORMATION

Note to Adults: To ensure that the child's play is both safe and fun, please review all operating instructions and safety rules with your child.

Safety tips

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion. Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.

TO avoid accidental operation, remove all batteries when not in use.

BATTERY SAFETY INFORMATION

- Insure that battery polarity is correct.
- Use only batteries of the type recommended (or equivalent).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Remove used-up batteries immediately. Recharge or dispose of vehicle but not be used for a long period.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit terminals.
- Remove rechargeable batteries before recharging.

QUICK TIPS

1. When your vehicle starts to lose power, it may lose functions or perform poorly. It's time for fresh batteries for a recharge! Your vehicle's running time may change depending on your driving style.
2. Radio interference can make your vehicle run badly. Interference can be caused by other RC vehicles, turning on the same frequency, electrical wires, large buildings, or CB radios. Try to stay away from these!
3. Post your transmitter on top of your vehicle. If your vehicle gets too low, a short work probably if your transmitter has a carry-loop feature, make sure the antenna is positioned horizontally. Keep the antenna clear of any obstacles before operating.
4. Don't drive your vehicle in sand or through water or snow.
5. Don't store your vehicle near heat or direct sunlight. Always turn switches OFF and remove all batteries for storage.

TROUBLESHOOTING - PROBLEM? - SOLUTIONS

SYMPTOM

Vehicle runs slowly or not at all.

- Loose battery connection in vehicle speech reel ON.
- Wrong or antique rechargeable NiCd battery.
- Wrong transmitter battery.

CORRECTION

- Check battery connector and vehicle switch.
- Change battery or replace.
- Replace with high alkaline battery.

Power indicator light or transmitter does not light.

- Transmitter battery weak or not connected.

Erratic operation or only short range possible.

- Radio interference likely.
- Antenna is straight and carry-loop holder (if equipped).
- Check connections and replace battery if required.

Vehicle doesn't work after going through water or snow.

- Vehicle will take several hours to dry. Allow to dry thoroughly overnight before trying again.
- Avoid driving in water or snow.

90-DAY LIMITED WARRANTY - TIGER RC PRODUCTS

Model kit warranties in the United States are provided by the manufacturer. The product will be free of defects in material and workmanship for 90 days after the date of purchase. Model kit warranties in the rest of the world are provided by the manufacturer. Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer. The product will be free of defects in material and workmanship for 90 days after the date of purchase. Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer. The product will be free of defects in material and workmanship for 90 days after the date of purchase. Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.

Model kit warranties in the rest of the world are provided by the manufacturer.