

User's Guide

Supporting the handsfree and headset profile

Compatible with Nokia: 8910, 8910i, 6310, 6310i, 6600, 3650, N-Gage, N6230, 6820 Ericsson:T39, T68 Sony Ericsson:T68,T68i,T610, T630, P800, P900, Z600 Philips: Fisio820, Fisio 826 Panasonic: X70 Siemens:S55, SX1, Motorola:V525, V600, A760 Sharp: GX-T15, GX-T21,GX-T31



1.Charging the battery:

When the battery is new, it is not fully charged. It takes 4 hours to fully charge the battery. Afterwards it will take 2 hours to fully charge the battery. There are two modes of charging:

(1) Plug the travel charger into the AC outlet and the indicator of the adaptor will turn on. Connect the adaptor into the charging status of the headset. The red indicator of the headset will light on. When the battery is full, the red indicator will be off. Disconnect the adaptor from the headset.

(2) Plug the USB cable to the charging status of the headset. The red indicator of the headset will light on. The battery is now being charged. When the battery is full, the red indicator will be off. Disconnect the USB cable from the headset.

2.Turning the headset on or off:

(1) Press the “**Button 1**” for 5 seconds. You will hear two beep sounds and the blue indicator begins to flash every 3 seconds. The headset is now powered on.

(2) When the power is on, press the “**Button 1**” for 3 seconds. You will hear two beep sounds and the red indicator will flash, then the headset is turned off.

3.Pairing the headset:

(1) The headset must be powered off before you begin to initiate the pairing. Press the “**Button 1**” for six seconds, and the blue and red indicators will begin to flash alternatively. The headset is now in pairing mode.

(2) Initiate the pairing process of your bluetooth mobile phone. (Please refer to the manual of your mobile phone.)

(3) When asked the **PIN code**, please enter “**0000**” to successfully complete the pairing process.

(4) When the pairing process is successfully completed, the blue indicator will flash **3 times every 3 seconds**. The headset is now in standby mode.

Note:

(1) If the headset is not in pairing mode, your mobile phone can not find the headset. Please set the pairing the headset into pairing mode before you start to connect the headset with your phone.

(2) If no pairing is possible over a period of time (Aprox. 1minute), the pairing process will be stopped. You have to repeat **STEP 3** to successfully complete the pairing.

4.Answering or ending calls:

When the headset is paired with your phone, and when there is an incoming call, you will hear a musical beep. Then press the “**Button 1**” to answer the call. When there is a call in session, you can press the “**Button 1**” to end the call.

Note: Due to the different design of some mobile phones, an auto-disconnect may happen even when the Headset is powered on. In that case, the headset won't ring when there is an incoming call. Press “**Button 1**” for 1 second to reconnect the Headset with the mobile phone for an incoming call.

5.Making calls:

(1) **Voice-dialing:**

Press the “**Button 1**”. After hearing a beep sound, say the name of the person you recorded on your phone.

(The availability of this function depends on the design of the mobile phone you use. Please refer to the manual of your mobile phone for voice-dialing function.)

(2) Dial the phone number on you mobile phone as you normally do. The sound will be transmitted to the headset automatically.

6.Changing the volume of the Headset:

(1) Press the “**Button 2**” to increase the listening volume of the headset.

(2) Press the “**Button 3**” to decrease the listening volume of the headset.

(3) You can also adjust the volume from your mobile phone.

7.Redialing the call:

After ending the call, you can press the “**Button 2**” to redial the call you just ended.

(The availability of this function depends on the design of the mobile phone you use. Please refer to the manual of your mobile phone.)

8.Mute function:

You may have to keep a call on line while talking to others. Push the “**Button 2**” and the “**Button 3**” at the same time for one second. You will hear continuous beep sounds. Now the headset is in “**mute function**” mode. To disable the “**mute function**”, press the “**Button 2**” and the “**Button 3**” once again.

9.Rejecting a call

When there is a call in session, you can press the “**Button 1**” for three seconds to reject a call.

Function of Buttons:

Button 1: Turning on or turning off the headset, Pairing, Answering or Ending a call, Voice-Dialing, Rejecting a call

Button 2: Volume-up, Redial

Button 3: Volume-down

Button 2 + Button3: Mute function

Trouble Shooting:

1.the red indicator flashes.

-It indicates that headset is in low-battery. Charge the batter until the red indicator is turned off.

2.If no connection between the headset and your phone.

-Make sure that the bluetooth headset is on.

-Repeat the step 3 to complete the pairing process.

-Make sure that the headset is within 10 meters of your phone and that there are no obstructions such as walls or other electronic device between the headset and your phone.

-the pairing list maybe full. The headset pairing list can store the information up to 8 phones at a time. If the list is full, reset the headset to the original settings.

3.The headset can not be activated after being charged for 20 minutes.

-To activate the battery, it need to charge the battery at least 40 minutes.

Product Care

-Avoid humidity, liquid or moisture.

-Avoid high and low temperature, especially in a car.

-Do not dissemble the headset.

-Do not use chemical, cleaning solvents or strong detergent to clean the headset.

FCC Regulation:

● This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

● This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

● The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.