

# **KODAK 10 Inch WIFI Photo Frame**

**Quick Start Guide** 

Step2: Link your frame to the

**KODAK WIFI Photo Frame application.** 

3. Open the KODAK app. Input the Frame ID# or scan the QR

Code to sync your device to this frame. You can find the 10

4. Once complete, you can verify the ID# by tapping on "My

Device(s)." You may choose to prevent new devices from

connecting to Frame, disconnect your phone from the

frame under manage device, and check whether the


digit UN serial number under the QR Code on the Device


Sync tab. Tap "Confirm" to complete this process.

frame is online.

## **Getting Started**

1. Plug in the power adapter 2. The first time you power on your KODAK 10 Inch WIFI Photo Frame (RWF-108), the process will take 3-5 minutes to get to the Wi-Fi setting menu (the KODAK logo will stay on the screen). After the initial set up, the process will take less than 30 seconds if you power the frame off and on again.





Step2: Link your frame to the

The KODAK WIFI Photo Frame app is now linked

To post pictures from the KODAK App to the frame

B. Select the picture that you want to send to the frame, (maximum of 6 photos each time)

D. Tap "Send" to send the picture/pictures to the

to check the progress. You may also check by

frame. You will see a status bar on the main menu

E. Tap your account name and tap "Click to check

photos" to view your photos or "Delete account"

C. Tap "Send" on the bottom of the screen

5. Congratulations!

please follow below steps

tapping"record".

A. Tap on "Album" or "camera".

to confirm the picture selection.

to delete your account and photos.


**KODAK WIFI Photo Frame application.** 

## Step1: Connecting to a wireless network

## Go to Settings



Wireless Setting: 1. Select the Network you want to connect to 2. Use the keyboard to enter the Password 3. Press Connect



### Step2: Link your frame to the **KODAK WIFI Photo Frame application.**

Linking your frame to the KODAK WIFI Photo Frame app will allow you to send pictures directly from your tablet or smart phone

### Tap "settings" and find "Device Sync."

1. You can download the KODAK WIFI Photo Frame app by A) scanning the QR Code that appears in the Device Sync tab or B) you can find it on both the App Store and Google Play, by searching "KODAK WIFI Photo Frame."

2. Once the App is downloaded, please start the app by tapping the KODAK app icon. If this is your first time using the application, you must create a new account by entering the following data: email/password/confirm password/nickname. Then tap "Confirm."

If you don't want to sign in or create an account, you only can use it as a digital photo frame.

Model:RWF-108

Thefo BEF

Section 1999

On time

Orden 🕢

Orden ()

On time


# **Step 3: Review & Operate Photos** On The Device



Tap photos to access the toolbar with the following options: Favorite/Rotate/Scale/ Play/ Delete/Zoom/Setting/Info



Tap setting: Calendar: on/off Transition Effect: Random/ Up to down/Down to up/



10mins/1hour/24 hours Background Music: on/off

# **Technical Support:**

If you need further assistance, please contact the support department E-mail: support@maxtdigital.com Web: www.maxtdigital.com/kodakframes

All information contained in this document is subjected to change without notice.

# Radio and TV Interference Statement

WARNNING!!! This equipment has been tested and found to comply with the limits of a Class B  $digital\ device, pursuant\ to\ part\ 15\ of\ the\ FCC\ rules.\ These\ limits\ are\ designed\ to\ provided and the provided and the provided are designed\ to\ provided and the provided are provided as the provided are designed\ to\ provided\ to\ provided\ the provide$  $reasonable\ protection\ against\ harmful\ interference\ in\ a\ residential\ installation.$ This equipment generates, uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is  $encouraged \ to \ try \ to \ correct \ the \ interference \ by \ whatever \ measures \ may \ be \ required \ to$ correct the interference

# Maxtalent warrants this product against defect in material or workmanship for 1 YEAR from the

This warranty becomes invalid if the factory-supplied serial number or "warranty void" stickerhas been removed or altered on the product.

This warranty does not cover A) Cosmetic damage or damage due to acts of God.

B) Accident misuse, abuse, negligence or modification of any part of the product. C) Damage due to improper operation or maintenance, connection to improper equipment or attempted repair by anyone other than Maxtalent or appointed. D) Products sold AS IS or WITH FAULTS.

FROM DIRECT INDIRECT, SPECIAL, INCIDENTAU OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION Maxtalent makes no warranty or representation, expressed, implied,

IN NO EVENT SHALL MAXTALENT LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT

or statutory, with respect to products, contents or use of this  $documentation \, and \, all \, accompanying \, software, and \, specifically$ disclaims it's quality, performance, merchantability, or fitness for any particular purpose



The Kodak trademark, logo and trade dress are used under license from Kodak. © 2019 Maxtalent Industrial Limited. All rights reserved, All information contained in this document is subject to change without noitce Made In China

© IC **€** RoHS

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.