

**Operation Manual:** Please read this manual carefully before operation. Please keep this manual for any needed future reference.

### ⚠ WARNINGS!

- Improper use of battery may lead to dangers such as heat, breakage or leakage. Note the following items:
- Strictly observe the methods and cautions of the operation manual
  - Leakage from the battery may cause skin irritation. Recommendation is to immediately and thoroughly cleanse the irritated area with soap and water.
  - Do not place battery into water or fire or puncture the battery.
  - Dispose of any exhausted batteries properly.
  - Leakage from the battery that has come in contact with the eye may cause blindness. Cleanse the polluted eye immediately and consult doctor's advice on further treatment
  - Do not use, charge, or store batteries in places that are in close proximity to fire, heat, or moisture.
  - CAUTION-ELECTRIC TOY**-Not recommended for children under 8 years of age. As with all electrical products, precautions should be observed during handling and used to reduce the risk of electric shock

### ⚠ CAUTIONS!

- Make sure to switch off after play.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed as it may affect operation of the R/C.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy and disposed of properly.
- The supply terminals are not to be short-circuited.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The toy is not to be connected to more than the recommended number of power supplies.
- The antenna is not to be inserted into any light sockets or wall outlets.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receive is connected
  - Consult the dealer or an experienced radio/TV technician for help.

### Method of Taking the Car out from the Foam.

- Use a pair of scissors to snip the string under the foam. (See Illustration I.)
- Take the Car out from the foam. (See Illustration II.)




Illustration I






Illustration II

### Loading & Unloading of the Battery of Remote Controller

- Using 9V battery.
- Follow the arrow direction to remove the battery cover.
- See below illustration. Install the 9V battery after checking the positive and negative polarity, replace the battery cover.
- The duration for continuous operation of the remote controller battery is 8 hours.




### Loading & Unloading of the Batteries of Toy Car



- Using 6 x 1.5V AA alkaline batteries.
- Turn the switch "OFF"
- See above illustration. Remove the battery cover by loosening screw, install the 6pcs AA batteries inside the battery grooves following the positive and negative polarity as shown on each battery groove, replace the battery cover over the battery compartment and affix the cover by re-tightening the screw.
- When the AA batteries are exhausted, Turn "OFF" the switch, loosen the screw on the battery cover, remove the battery cover, take out the exhausted AA batteries, and dispose of exhausted batteries properly. Reinstall new AA batteries.

- Remarks:
- Don't connect the toy to the voltage which is higher than recommended.
  - Make sure the loading & unloading of the batteries of the toy car is under adult supervision.
  - Remove batteries before storing car for extended period of time.


### Indication for the Function of Remote Controller



#### Cautions:

- The car runs in fast speed, please make sure to keep others away to avoid crash or damage to car.
- Make sure not to insert fingers or other objects into the gaps between wheels & axles when playing to avoid any accidental injury.

### Cautions in Operation



- ⚠ Caution: Don't insert fingers or other objects into the gaps between the wheel and car body. Operation should only be performed under close adult supervision. Don't touch the wheels or the front frame joining when the car switch is turned "ON".
- ⚠ Caution: Don't brandish the antenna or point the antenna toward anyone's face as accidental injury could occur in the event the antenna tip went into the eye. Should the antenna be damaged in any way, please be sure to replace it due to the possibility of injury. Do not place the antenna into any socket so as to avoid electric shock.
- ⚠ Caution: Don't play with the car on roads or in crowded places to avoid accident or injury. Also, don't run the car on the restive places such as a wet or sandy surface as this shall lead to breakdown of the toy.

**Warning:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.