

Meisida Eagle Radio Control Series

Radio Control Battle Tank

MSD0349



Operation Manual

(Please read this manual carefully before operation)



Meisida Electronic Toys Co.,Ltd.

Add:No.1 of the 8th Block of Anping Development Zone, Anhai,Jinjiang,Fujian,China
Tel:0595-5788889 Zip Code:362261 Cable:4388
Executing Standards: GB6675-86, GB52965-1996
Suitable Ages:Over 8



⚠ Warnings!

1.How to use the charger

- In case of smoke, strange smell or noise, operation shall be stopped in order to avoid fire or electric shock. Pull the plug and get ready for repair after confirming that there is no more smoke.

2.How to use the battery

- Leakage from battery may lead to blindness. Clean the polluted eye immediately with clear water and consult doctors thereafter.

- 3.Warning: Do not insert the fingers into the clearance in case of any danger while the car is in movement.



⚠ Cautions!

1.How to use the charger

- Do not touch the plug or socket with wet hand to avoid electric shock.
- Pull the plug upon completing the charge for the risk of fire.

2.How to use the battery

- (Improper use of battery may lead to dangers such as heat, breakage or leakage. Note the following items)
- Strictly observe the methods and cautions of the operation manual.
 - Avoid short circuit as it may lead to great currents.
 - Leakage from the battery may hurt skin. Clean the skin when contaminated.
 - Do not drop the battery into water or fire or even dissolve the battery.



⚠ Cautions!

- Do not use ,charge or store the battery in places that are close to fire or heat or moist.
- Do not charge the battery upon fulfillment.Overcharging may be hazardous.
- Make sure to install the positive pole and negative pole correctly.
- Make sure to switch off and take out the battery after play.

3.Cautions in operation:

(Please note the following items for the sake of avoiding accidents)

- Play on roads or crowded places may be risky,choose a safe outdoor place for operation.
- Do not distort the antenna or twist may injure people.
- Do not damage glass or furniture when play indoors.
- Avoid the risk of finger or hair's being involved when the wheel is in operation.

4.Rules for play


- Do not run the toy car on rainy day or wet surface,this shall lead to breakdown of the car.
- Avoid operation on soil or fine sand.
- Do not store the car in heating room or places next to fire.
- Do not play outdoors when thundering.
- Do not play near some wireless transmitting facilities.
- Do not play near some radio control car which is of the same frequency so as to avoid being interfered.

Material used: Plastic, hardware, Electronic oven


⚠ Cautions!

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with limits for a Class B digital-device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, these is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - 1, Reorient or relocate the receiving antenna.
 - 2, Increase the separation between the equipment and receiver.
 - 3, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4, Consult the dealer or an experienced radio / TV technician for help.

Cautions in operation:



⚠ Caution: Avoid the risk of finger being involved when the wheel is in operation.




⚠ Caution: Do not brandish the Antenna or closed your face to Antenna, or it may injure eyes. Please replace the broken off Antenna.



⚠ Caution: Do not play on roads with crowded places, soil or fine sand.

Method of Charging the Battery

9. 6V Charger



Correct way of charging


1. The battery shall be installed correctly on the charger, see the illustration.
2. Plug the charger into a household socket.
3. Charge duration is 4 to 6 hours. No charge is allowed after this. (It takes about 8 hours for the first charge time.)
4. Pull the charger off the socket after finish charging.

Cautions:

- ▲ The attached battery is not charged yet. Make sure to charge it prior to use. In the course of charge, it is normal that temperatures of the charger and the battery will be on the rise.
- ▲ Charging the battery must be performed by an adult.


Loading&Unloading of the Battery

1. Open the battery cover on the back of the remote controller and install 9v laminated battery after check the positive and negative poles. See the illustration.
2. Cover the battery.
3. The indicator lights up when the switch is "ON" position to show the battery has been installed properly. Otherwise, install again according to the procedures above.
4. The duration for continuous operation of the remote controller is 8 hours.



— 6 —


Loading&Unloading of the Battery of the Car




1. Confirm that switch is at the position of "OFF".
2. Turn loose the lock of battery cover and open the battery cover, join the plug of the battery and the plug of the power supply of the car, put the battery inside the battery case, cover the battery case and fasten the lock to close the cover.
3. When re-charging battery is needed, please put off the switch, loose the battery lock and open the battery cover, take out the battery then charge it.

— 7 —

Operation Methods




Operation Methods



Operation Methods

Launcher the missile:
Press the right button
on the front of the
controller, then the
missile will launch
with flashing lights
and action sounds.



Battel up&down

Cautions:

- 1) Take foam missiles and insert them into the turret's hole, rotating them until they lock into place.
- 2) If there is difficulty in loading any of the missiles, do not force it in. Press the missile launching button on the remote control and try reloading the missile again.

Warnings:

- 1). Do not face the turret away from yourself and others!
- 2). Do not use any of the missiles if the foam material has been removed.
- 3). Do not use any other materials as the missiles.
- 4). Avoid to push the Missile Launcher button for long time.

Analysis of Breakdowns

Before sending out for repair, readjust the car because most of the breakdowns have been caused by low battery.

Conditions of the Car	Reasons	Ways for Inspection & Adjustment	Relevant Pages
Stop Working	No battery in the remote controller or the car	Reloading the battery	6
	Incorrect installation of the battery of remote controller	Reinstalling the battery	5
	Low battery of the remote controller	Changing for new battery	5
	Low battery of the car	Recharging	6
Out of Control	Low battery of transmitter is different from the one of tank.	Changing for new battery	5
	Interference by some waves	Changing for new place	
	Operation of remote control car at the same cycle nearby	Changing for new place	
Note: Except the reasons mentioned above, please send out for repair.			

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**