

Meisida Eagle Radio Control Series

STREET SAVAGE

MSD0460



Operation Manual

(Please read this manual carefully before operation)



Meisida Electronic Toys Co.,Ltd.

Add: No.1 of the 8th Block of Anping Development Zone, Anhai, Jinjiang, Fujian, China
Tel: 0595-85788889 Zip Code: 362261 Cable: 4388
E-MAIL: meisidatoy@163.com
<http://www.meisida.com>
Executing Standards: GB6675-2003, GB5296.5-1996
Suitable Ages: Over 6+



⚠ Warnings!

1. How to use charger

- ▲ In case of smoke, strange smell or noise, operation shall be stopped in order to avoid fire or electric shock. Pull the plug and get ready for repair after confirming that there is no more smoke.
- ▲ Do not touch the plug or socket with wet hand to avoid electric shock.
- ▲ After finish charging (charge duration normally is 4 ~ 6 hours) pull the charger off the socket. Strictly prohibit keeping plug into the socket for a long time. Otherwise it may lead to overheating, fire, electric shock and other unsafe hidden trouble.



⚠ Cautions!

2. How to use the rechargeable battery

- ▲ The rechargeable battery contains Nickel-Cadmium, please strictly observe the methods and cautions of the operation manual.
- ▲ Avoid short circuit when using or placing as it may lead to great dangers, such as fire, explosion. Meanwhile, do not store the battery in high-temperature room or places next to fire.
- ▲ Do not use the breakage or/and leakage battery.
- ▲ Do not throw the battery into fire or water for destroy or even dissolve scrap or disuse the battery in case of pollution and hurt lead from the chemic element of the battery.



⚠ Warnings!

- ▲ Non-rechargeable batteries are not to be recharged;
- ▲ Rechargeable batteries are to be removed from the toy before charged;
- ▲ Rechargeable batteries are only to be charged under adult supervision;
- ▲ Different types of batteries or new and used batteries are not to be mixed;
- ▲ Only batteries of the same or equivalent type as recommended are to be used;
- ▲ Batteries are to be inserted with the correct polarity;
- ▲ Exhausted batteries are to be removed from the toy;
- ▲ The supply terminals are not to be short-circuited;
- ▲ The antenna is not to be inserted into socket outlets;
- ▲ Transformers used with the toy are to be regularly examined for damage to cord, plug enclosure and other parts ; and in the event of such damage, toy must not be used with the transformer until such damage has been repaired;
- ▲ The toy is not to be connected to more than recommended number of power supplies;
- ▲ The toy is not intended for children under 3 years old;
- ▲ The toy must only be used with the recommended transformer;
- ▲ The transformer is not a toy.


Cautions!

3. Rules for play

- ▲ The car is for 6 ages up group only.
- ▲ Do not play the car outdoors when thundering.
- ▲ Do not run the toy car on rainy day or wet surface.
- ▲ Do not play near some wireless transmitting facilities.
- ▲ Do not play near some radio control car which is of the same frequency so as to avoid being interfered.
- ▲ A potential danger possibly exists for the toy's functional sharpness and edge. Please play the toy car under adult supervision.
- ▲ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- ▲ This equipment has been tested and found to comply with limits for a Class B digital-device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - 1, Reorient or relocate the receiving antenna.
 - 2, Increase the separation between the equipment and receiver.
 - 3, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4, Consult the dealer or an experienced radio / TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Cautions in operation:



⚠ Caution: Avoid the risk of finger being involved when the wheel is in operation. Don't insert finger into the car body and touch the wheels when the car turn "ON" or in work. in case of danger.




⚠ Caution: Do not brandish the Antenna or closed your face to Antenna, or it may injure eyes. Please replace the broken off Antenna.



⚠ Caution: Do not play on roads with crowded places, soil or fine sand.

Method of Charging the Battery:



Method of charging the battery:

1. See the illustration. Use the appropriate charger to charge.
2. Install the 6.0V battery pack in the direction of arrow into the charger. Then plug into household socket appropriate.
3. Charge duration normally is 4~6 hours. No charge is allowed after this. (In its first time of charging it must need about 8 hours.)
4. Pull the charge off the socket after finish charging. Press the lock of battery in charger and take out the battery pack.

- Notes:
1. The attached battery is not charged yet. Make sure to charge it prior to use. In the course of charging it is normal that temperature of the charger and battery will be on the rise.
 2. Termly check the plug, crust and other parts if they are in good condition. If breakage found should be stop using until repair into good condition.
 3. The charger and battery are not toys. They should be charged and used under adult supervision.