

Jet Warrior

MSD2201



Instruction Manual



(Please read this manual carefully before operation)

Meisida Electronic Toys Co.Ltd

Add: No.1 of the 8th Block of Anping Development Zone, Anhai, Jinjiang FuJian, China

Tel: 0595-5788889 Zip Code:362261 Cable:4388

Executing standards: GB6675-86, GB5296.5-1996

Suitable Age: Over 6



Warnings!

1. How to use the charger

- In case of smoke, strange smell or noise, operation shall be stopped in order to avoid fire or electric shock. Pull the plug and get ready for repair after confirming that there is no more smoke.
- The voltage can not over 220v in order to avoid fire or electric shock.

2. How to use the battery

- Leakage from battery may lead to blindness. Clean the polluted eye immediately with clear water and consult doctors thereafter.



Cautions!

1. How to use the charger

- Do not touch the plug or socket with wet hand to avoid electric shock.
- Pull the plug upon completing the charge for the risk of fire.

2. How to use the battery

(Improper use of battery may lead to dangers such as heat, breakage or leakage. Note the following items)

- Strictly observe the methods and cautions of the operation manual.
- Avoid short circuit as it may lead to great currents.
- Leakage from the battery may hurt skin. Clean the skin when contaminated.
- Do not drop the battery into water or fire or even dissolve the battery.



Cautions!

- Do not use ,charge or store the battery in places that are close to fire or heat or moist.
- Do not charge the battery upon fulfillment.Overcharging may be hazardous.
- Make sure to install the positive pole and negative pole correctly.
- Make sure to switch off and take out the battery after play.

3.Cautions in operation:

(Please note the following items for the sake of avoiding accidents)

- Play on roads or crowded places may be risky,choose a safe outdoor place for operation.
- Do not distort the antenna or twist may injure people.
- Do not damage glass or furniture when play indoors.
- Avoid the risk of finger or hair's being involved when the wheel is in operation.


4.Rules for play

- Do not run the toy car on rainy day or wet surface,this shall lead to breakdown of the car.
- Avoid operation on soil or fine sand.
- Do not store the car in heating room or places next to fire.
- Do not play outdoors when thundering.
- Do not play near some wireles transmitting facilities.
- Do not play near some radio control car which is of the same frequency so as to avoid being interfered.


Material used: Plastic, hardware, Electronic oven

Names of Parts

Car Body




Remote Controller




Accessories

Charger



INPUT: AC-220V 50Hz
OUTPUT: DC-6.75V 200mA

6V chargeable battery




9V laminated battery



Method of Charging the Battery


1. The battery shall be installed correctly on the charger, see the illustration.
2. Plug into a household socket.
3. Charge duration is 4 hours. No charge is allowed after this.
4. Pull the charger off the socket after finish charging.

Note) The attached battery is not charged yet. Make sure to charge it prior to use. In the course of charge, it is normal that temperatures of the charger and battery will be on the rise.




Loading & Unloading of the Battery

1. Open the battery cover on the back of the remote controller and install 9v laminated battery after check the positive and negative poles. See the illustration.
 2. Cover the battery.
 3. When the remote controller malfunction, follow step 1 and 2 to reload the battery.
- The duration for continuous operation of the remote controller is 8 hours.





Loading & Unloading of the Battery of the Jet

See the following illustration, put the 6.0v battery which is full charged inside the battery case of the Toy Car. Cover the battery case and fasten the lock to fix the battery.





Operation Methods



Forward: Push the left-side and right-side drive forward together. It can control the plane forward.





Forward and Turn Right: Push the left side drive forward. It can control the plane turning right.



Backward: Push the left-side and right-side drive backward together. It can control the plane backward.




Forward and Turn Left: Push the right side drive forward. It can control the plane turning left.




Transform

Pressing the right top button of the remote controller, then the Jet warrior transforms from Robot to plane.





Transform

Pressing the left top button of the remote controller, then the Jet warrior transforms from plane to Robot.



Spin Vertically

Push the left sticker forward(backward), and the right sticker backward(forward), the Jet warrior can spin vertically.



Prior to Any Breakdown

Readjust the toy car before sending for repair, because the breakdown is largely caused by low battery

Conditions of the Car	Reasons	Ways for Inspection & Adjustment	Relevant Page
Stop Working	No battery in the remote controller or the car	Reloading the battery	5-6
	Incorrect installation of the battery of remote controller	Reinstalling the battery	5
	Low battery of the remote controller	Changing for new battery	5
	Low battery of the car	Recharging	4,6
Out of Control	Low battery of the remote controller	Changing for new battery	5
	Hindered by the electric wave	Changing for new place or wait for a few seconds	
	Operation of radio control car at the same frequency nearby	Changing for new place or wait for a few seconds	
Easy Exhaust of Battery or Hard Acceleration	Low battery	Recharging	4,6
	Life Performance	Changing for new battery	6

NOTE:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device'