











Table of Contents

01 - 10 English
01 - 10 简体中文
11 - 19 日本語
20 - 29 Deutsch
30 - 39 Français
40 - 49 Español
50 - 59 Italiano

01 Warnings English

- To ensure proper use and trouble-free operation, please carefully read this user manual first.
- For the first use, a full charge is recommended.
- Please use and store the product at room temperature.
- Do not throw and drop the product to avoid damage.
- Do not expose the product to fire, high temperature, direct sunlight, etc.
- Do not use organic solvents or other chemicals to clean the product.
- Do not allow small particles to get into the product.
- Please keep volume of the speaker moderate to avoid temporary or permanent hearing impairment.
- Do not disassemble the product, or make any modifications to the structure or any parts of it.
- Keep the product out of children's reach.



10 Specifications English

Basic Parameters	Bluetooth Speaker
Speaker Type	Bluetooth Speaker
Supported Charge	USB, DC 5V Micro USB and (4x1.5)
Battery	Built-in 400mAh 1835mAh battery
Power Supply	DC5V-1A (at least) USB or the adapter
Technical Parameters	
Two-speaker	Built-in two external magnetic speakers + 10W low-frequency amplifier
Peak Output Power	20W
Frequency Response	50Hz-15KHz
Bluetooth Standard	4.2
USB Standard	USB 2.0 (compatible with USB 1.1)
Plug-in Parameters	
Supported Media Type	APL, FLAC, MP3, WMA, AAC

Size: 8.9 x 3.1 x 1.8 in (226 x 80 x 42 mm)
Weight: 5.6 oz (158 g) (including the built-in Lithium battery)

11 Troubles Shooting English

FAQ	Solutions
How do I connect to my device?	1. Ensure the speaker is in pairing mode. 2. If your device requires a Pin Code, please enter 0000.
How do I connect to another playing device?	1. Please ensure the speaker is in the pairing mode and there are no connection between the speaker and the device. 2. Please ensure the device is in the pairing mode.
No sound when playing music on Micro SD card	1. Please ensure the format of the Micro SD card is FAT32. It only supports FAT32 Micro SD card. 2. Please ensure the format of the music files is MP3, AAC, WMA, WAV or MP2. 3. Please adjust the volume of the speaker. 4. Please adjust the volume of your device.
No sound when playing	1. Please check if the speaker is powered on. 2. Please ensure the audio cable is connected well. 3. Please try to charge the speaker for about 1 hour.
No sound in AUX-in mode	Please try to connect to another device.
No sound in USB mode	Please try to charge the speaker for about 1 hour.
No response in any operation	Please try to reset the speaker by pressing the reset button on the AUX-in jack.

MIFA MIFA INNOVATIONS LLC
www.mifa.com.cn Chicago, IL, USA Made in China

Copyright © MIFA. All rights reserved.
MIFA, the MIFA logo and other MIFA marks are all owned and registered by MIFA INNOVATIONS LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.