




JUST ENJOY

Mifa MIFA INNOVATIONS LLC www.mifa.net Designed in US Made in China

Copyright © Mifa. All rights reserved. Mifa, the Mifa logo and other Mifa marks are all owned and registered by Mifa Innovations LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.

Mifa



A60 Bluetooth Speaker

USER MANUAL

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

01 Warnings


English



- ◆To ensure proper use and trouble-free operation, please carefully read this user manual first.
◆For the first use, a full charge is recommended.
◆Please use and store the product at room temperature.
◆Do not throw and drop the product to avoid damages.
◆Do not expose the product to fire, high temperature, direct sunlight, etc.
◆Do not use organic solvents or other chemicals to clean the product.
◆Do not allow small particles to get into the product.
◆Please keep volumes of the speaker moderate to avoid temporary or permanent hearing impairment.
◆Do not disassemble the product, or make any modifications to the structure or any parts of it.
◆Keep the product out of children's reach.

02 Packing Contents

English



1 X A60 Speaker



1 X 3.5 mm Audio Cable



1 X Micro USB Cable



1 X User Manual

03 Keys Functions

English


Power Button: Press and hold it for 2 seconds to turn on/off the speaker

Mode: Double press it to switch modes in turns as followed: Bluetooth mode -- Micro SD card mode -- AUX-in mode (if it works with a Micro SD card and an Aux cable)

Play/Pause: Press it to pause/continue the playing
Call Answer: Press it to answer/hang up the call; press and hold it to decline the call

Bluetooth Disconnection: Press buttons "+" "-" simultaneously to disconnect the device and then the speaker becomes detectable for pairing.

Press the Button "P" to reconnect the speaker with the last used device.



PREV Button: Press it to play the previous track
Volume -: Press and hold it to turn down the volume


NEXT Button: Press it to play the next track
Volume +: Press and hold it to turn up the volume

Sleep-aid Mode Button: Press and hold it to play the built-in sleep-aid music; press and hold it again to exit. Press it to select a power-off timer among 30 minutes, 60 minutes and 90 minutes.

04 Screen Descriptions

English

Playing Status: It disappears when playing is paused.



Time Setting: Turn off the speaker and then charge it with a USB charging cable. Press and hold buttons "+" "-" simultaneously to enter into the setting interface. Press buttons "+" "-" to set the hour and save the setting by pressing "P". Press buttons "+" "-" again to set the minute and save the setting by pressing "P". If you want to cancel the settings and exit, press "P".

Prompt:

- 01. The speaker will automatically turn off after 10 minutes if there is no manual operation and no device connected.
02. If you want the screen to keep showing the current time even if in the power-off status, please keep it being charged.
03. If the speaker plays music on the Micro SD card, the screen does not show the current time; if the speaker is playing sleep-aid music with a timer, the screen does not show the current time either.



Micro SD card playing Showing the selected track




Volume adjustment screen 31 means the max volume



When the speaker is being charged, battery indicators flicker. When the battery is charged full, battery indicators keep on.

05 Interfaces Function

English



Aux-in Jack Reset Button: There is a reset button in the jack. It can be pushed by a needle-like object to reset the speaker. (The speaker can also be reset by pressing and holding the power button for 8 seconds.)

Charging: Charge the speaker with a DC5V--1A (at least) USB charger.

Data Transmission: When the speaker is turned off, insert a Micro SD card in the slot and then connect the speaker to a computer via a Micro USB cable. Press the power button to enter into Card Reading Mode. Now you can copy and save files to the Micro SD card.


Micro SD Card Playing: Insert a Micro SD card after turning on the speaker. It will play music files on the card automatically.

06 Bluetooth Connection

English

1. Turn on the speaker

Press and hold the power button for 2 seconds to turn on the speaker (you will hear a sound of Ding Dong). It beeps and the Bluetooth icon flickers on the screen. The speaker is detectable via Bluetooth.



2. Connect to a Bluetooth device

Activate the Bluetooth of the mobile device and search for the speaker. Select Mifa_A60 on the list. It beeps and the Bluetooth icon keeps on when it succeeds in connection.


The speaker will connect to the device nearby automatically if the Bluetooth is activated in the future.

Other Instructions:


If you want to pair the speaker with another device, press and hold buttons "+" "-" simultaneously to disconnect the current device and the speaker becomes detectable.

07 TWS Function

English



Speaker 1



Speaker 2

1. Set up the TWS system

Turn on two A60 speakers and make sure neither of them is paired with a mobile device. Press and hold one speaker's buttons "+" "-" simultaneously. It beeps and the speaker begins to connect with the other one. After a sound of Ding Dong, the TWS system is set up successfully.

*For the first time setting up the TWS system, this speaker will act as the main speaker and the other one will act as the corresponding speaker.

2. Connect the speakers to a mobile device

Activate the Bluetooth and search for Mifa_A60. Select it once it's on the list. It beeps and Bluetooth icons keep on indicating a successful connection between the device and the speakers.

3. Disable the system

Press and hold either speaker's buttons "+" "-" simultaneously to disconnect the mobile device and disable the TWS system. Press "P" to reset up the TWS system.


Other Instructions:

- 01. The main speaker is the left channel and the corresponding speaker is the right channel.
02. The TWS system supports two speakers only.
03. Under the TWS system, you just need to operate either speaker. The other one will do the same operation simultaneously.


08 Specifications

English


Table with 2 columns: Parameter and Value. Includes Basic Parameters (Speaker Type, Supported Storage, Battery, Charging Time), Technical Parameters (Loudspeaker, Peak Output Power, Frequency Response, Bluetooth Standard, USB Standard), and Playing Parameters (Supported Media Type).



154mm



78mm



148mm

Size: 6.1 X 2.6 X 5.8 in / 154 X 78 X 148 mm
Weight: 13.4 oz / 380 g (including the built-in Lithium battery)

09 Troubles Shooting

English

Table with 2 columns: FAQ and Solutions. Lists common issues like 'Not able to connect to your device', 'Keeps cutting out when playing', etc., and their corresponding solutions.

Mifa MIFA INNOVATIONS LLC www.mifa.net Designed in US Made in China

Copyright © Mifa. All rights reserved. Mifa, the Mifa logo and other Mifa marks are all owned and registered by Mifa Innovations LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.