

## midlandusa.com

#### MIDLAND RADIO CORPORATION

5900 Parretta Drive Kansas City, MO 64120 Call 816.241.8500

We'd love to hear from you! Let us know what you think of your new Midland product on








or by visiting us at midlandusa.com

Note: Features & Specifications are subject to change without notice. MIDLAND is not responsible for unintentional errors or omissions on its packaging.

#### Welcome to the world of Midland electronics

Congratulations on your purchase of a high quality MIDLAND product. Your 2-way radio represents state-of-the-art high-tech engineering. Designed for GMRS (General Mobile Radio Service) operation, this compact package is big on performance. It is a quality piece of electronic equipment, skillfully constructed with the finest components. The circuitry is all solid-state and mounted on a rugged printed circuit board. Your two-way radio is designed for reliable and trouble-free performance for years to come.

#### **LCD DISPLAY**



- 1. TRANSMIT (TX) ICON Indicates
- radio is transmitting a signal.

  2. VOLUME METER Indicates the volume setting of the radio.

  3. RECEIVE (RX) ICON Indicates
- radio is receiving a transmission.

  4. LOW BATTERY ICON Indicates the
- 5. VOX ICON Indicates when VOX mode is active.
- 6. CHANNEL NUMBER Changes from 1~22 on GMRS/FRS band.
- 7. PTT Button Press and hold to transmit voice communication.
- SCAN/LOCK Button Press to enter
   SCAN mode. Press and hold to turn
   KEY LOCK on/off.
- UP ▲ and DOWN ▼ Buttons Make adjustments in MENU mode.
- 10. SPEAKER Built-in speaker.
- 12. EXTERNAL SPEAKER/MIC/CHG
- 13. POWER / MODE Button Press and hold for at least 3 seconds to turn the radio on/off. Press momentarily to access Menu mode.
- 14. MIC Built-in microphone

-(14)

#### **BATTERY INSTALLATION**

Your radio operates with 3 AAA alkaline batteries or NiMH rechargeable batteries. The belt clip should be removed to ease installation or removal of the batteries.

To install the batteries:

- 1. With the back of the radio facing you, remove the belt clip (see diagram below) for easy access, then remove the Battery Cover by pressing down on the top center and sliding it down from the radio.
- 2. Insert 3 AAA batteries observing the polarity as shown on the Battery Compartment. Installing the batteries incorrectly will prevent the unit from operating or may damage the unit.
- 3. Return the Battery Cover by sliding it up on the radio. Replace the belt



#### **CHARGING THE BATTERY**

Your radio is equipped for using rechargeable NiMH batteries which can be recharged by inserting the AC adapter into the radio charge jack. Initial charge time is 24 hours. Charge time is about 12 hours thereafter. For maximum battery life, we recommend charging the batteries when the low battery icon comes on. Remove the radios from the charger when the charge time expires.

- 1. Only use our NiMH batteries.
- 2. Do not attempt to charge alkaline batteries or any batteries or battery packs other than the one indicated in the manual. This may cause leakage and damage to the radio.
- 3. For long term storage of the radio, turn the radio OFF and remove the batteries from the radio.

#### **EXTERNAL SPEAKER/MICROPHONE JACK**

To use an optional speaker / microphone or headset:

- Insert the plug(s) into the SPK/MIC jacks.
- Place the earbud into your ear, and adjust the mic to



# IMPORTANT NOTICE, FCC LICENSE REQUIRED FOR GMRS OPERATION

The radios operate on GMRS (General Mobile Radio Service) frequencies which require an FCC (Federal Communications Commission) license. You must be licensed prior to operating on channels 1 - 7 or 15 - 22, which comprise the GMRS channels of the radios. Serious penalties could result from unlicensed use of GMRS channels, in violation of FCC rules, as stipulated in the Communications Acts Sections 501 and 502 (amended).

You will be issued a call sign by the FCC which should be used for station identification when operating the radio on GMRS channels. You should also cooperate by engaging in permissible transmissions only, avoiding channel interference with other GMRS users, and being prudent with the length of your transmission time.

To obtain a license or ask questions about the license application, contact the FCC at 1-888-CALL FCC or go to the FCC's website

## http://www.fcc.gov and request form 605. **Exposure To Radio Frequency Energy**

Your Midland radio is designed to comply with the following national and international standards and guidelines regarding exposure of human beings

- to radio frequency electromagnetic energy:
   United States Federal Communications Commission, Code of Federal
- Regulations: 47 CFR part 2 sub-part J - American National Standards Institute (ANSI)/Institute of Electrical &
- Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP)

To control your exposure and ensure compliance with the general population or uncontrolled environment exposure limits, transmit no more than 50% of the time. The radio generates measurable RF energy exposure only when

IMPORTANT: Changes or modifications to this unit not expressly approved by MIDLAND RADIO CORP. could void your right to operate this unit. Your radic is set up to transmit a regulated signal on an assigned frequency. It is agains the law to alter or adjust the settings inside the COMMUNICATOR to exceed those limitations. Any adjustment to your radio must be made by qualified.

## **OPERATING YOUR RADIO**

## **POWER ON/OFF AND VOLUME**

Press the POWER/MODE button for at least 3 seconds to turn the radio on/off. To increase/decrease the volume level, press the ▲I▼ buttons during RX or STANDBY mode. The VOLUME METER will indicate the volume setting of the radio.

## TRANSMITTING AND RECEIVING A CALL

- 1. For maximum clarity, hold the radio 2 to 3 inches from your mouth.
- 2. Press and hold the **PTT** button and speak in a normal voice into the microphone. The TX icon will appear continuously on the LCD display while transmitting.
- 3. To receive a call, release the PTT button. The RX icon will appear on the display when your radio is receiving a transmission

Your radio can scan all 22 channels for activity. To enter, quickly press the SCAN button. Repeat the same procedure to exit. Your radio will rapidly scan each of the 22 channels and stop on any active channel for 4 seconds before resuming scan. When you press the PTT button to transmit on an active channel, the scanning function will stop and remain on the active channel. To resume scanning, quickly press the SCAN button.

Your radio can transmit a call alert. To send, press the PTT button twice rapidly. The TX icon will appear while transmitting a call alert and a tone can be heard on the speaker for confirmation.

## **KEYPAD LOCK**

Press the **LOCK** button for 4 seconds. The "**Lo**" icon will appear on the display. **PTT** will still be active. Repeat the same procedure to unlock the keypad, a "**LF**" icon will appear on the display.

#### **CHANNEL SELECTION (GMRS/FRS BAND)**

Press the MODE button once, and then the AIV buttons to select one of the 22 GMRS/FRS channels. To confirm the selection, press the PTT button or press the MODE button again to move to the next feature setting. Note: To communicate between two radios, all radios in your group must be set to the same channel.

To turn VOX on, press the MODE button twice, the display shows "VOX" blinking while below the "oF" icon appears. Select "on" by pressing the ▲\▼ buttons and push the PTT key or the MODE button again to confirm. To turn VOX off, press the MODE button twice, the display shows "VOX" blinking while below the "on" icon appears. Select "oF" by pressing the ▲\▼ buttons and push the PTT key or the MODE button again to confirm.

#### **SPECIFICATIONS**

22 GMRS/FRS Channels

Operating Frequency UHF 462.5500 ~ 467.7125 MHz

3 AAA Alkaline or Rechargeable NiMH batteries

#### GMRS/FRS FREQUENCY CHART (MHz)

CH. No	CH. Freq.	CH. No	CH. Freq.	CH. No	CH. Freq.
1	462.5625	9	467.5875	17	462.6000
2	462.5875	10	467.6125	18	462.6250
3	462.6125	11	467.6375	19	462.6500
4	462.6375	12	467.6625	20	462.6750
5	462.6625	13	467.6875	21	462.7000
6	462.6875	14	467.7125	22	462.7250
7	462.7125	15	462.5500		
	100.000	4.0	100 5550	1	1

<sup>8 467.5625 16 462.5750

\*</sup> Channels 8~14 are low-power FRS license free channels

#### **ABOUT RANGE**

Your LXT Series radios are designed to give you maximum range under optimum conditions.



Maximum Range / Little to No Sight Obstruction



Short Range / Major Obstruction to Line of Sight

Optimum Conditions are:

- Open rural areas without obstructions
- Flat areas where you can see the other person

To ensure you get maximum range:

- Be sure to use fresh or fully charged batteries low batteries will cause low power conditions.
- Be sure you are on a GMRS channel FRS channels are restricted by the FCC to low power.

#### LIMITED WARRANTY

Midland Radio Corporation will repair or replace, at its option without charge, any Midland FRS/GMRS transceiver which fails due to a defect in material or workmanship within three years following the initial consumer purchase.

This warranty does not apply to water damage, battery leak or abuse. Accessories have a 90 day warranty from date of purchase, including any antennas, chargers, or earphones.

This warranty does not include the cost of labor for removal or re-installation of the product in a vehicle or other mounting

#### For Product Purchased in the USA:

Performance of any obligation under this warranty may be obtained by returning the defective product, prepaid freight, along with proof of

#### Midland Radio Corporation **Warranty Service Department** 5900 Parretta Drive Kansas City, MO 64120

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Note: The above warranty applies only to merchandise purchased in the United States of America or any of the territories or possessions thereof, or from a U.S. Military exchange.

#### For Product Purchased in Canada:

Performance of any obligation under this warranty may be obtained by returning the warranted product, along with proof of purchase, to your dealer in Canada.

This warranty gives you specified legal rights. Additional warranty rights may be provided by law in some areas.

# **MIDLAND**

# **ACCESSORIES**

Accessories can be purchased at midlandusa.com or by filling in the form on the following page and mailing it to the address on the form.

## AVP-1



AVP-H1

2 Over the Far w/ PTT

\$19.99

1 Open Face

Microphone Kit

# AVP-H4

AVP-H5



2 Far Wrap



# \$39.99





2 Rehind the Head Headsets

\$39.99

### TACTICAL HEADSETS TH1



TH3

Earphone Mic

\$39.99

Farphone Mic

\$29.99



TH2

\$109.99

Tactical Action Boom Mic with Tactical PTT

Action Throat Mic with Tactical PTT

and Pneumatic

**ACCESSORIES ORDER FORM** Please send Money Order or fill in Visa/MasterCard information and mail to the address below. Please **DO NOT** send cash or checks. Make Money Order payable to Midland Radio Corporation.

•				Zip Code:
C#:			Type: _	Ехр.:
Qty	Item	Price	Total	Mail To: Midland Radio Corporation
	AVP-1	\$19.99		Consumer Dept.
	AVP-H1	\$49.99		5900 Parretta Drive
	AVP-H2	\$49.99		Kansas City, MO 64120
	AVP-H3	\$39.99		Or Call 816.241.8500.
	AVP-H4	\$39.99		
	AVP-H5	\$39.99		To order online go to
	AVP-H7	\$39.99		midlandusa.com
	AVP-H8	\$39.99		
	TH1	\$39.99		
	TH2	\$99.99		
	TH3	\$29.99		
	TH4	\$109.99		

Sub-Total Tax (MO, FL, WA only) \$14.95 S & H (Applies to Domestic U.S. only. For Hawaii, Alaska, and Puerto Rico S&H will be \$36.25 for 1lb and \$64.25 for 2lbs or more).

Total

VP-H2	
-------	--



1 Closed Face Microphone Kit

\$49.99

\$49.99



AVP-H3

2 Surveillance Headsets

AVP-H8

AVP-H7

2 Mossy Oak Around the Ear Headsets with Boom Mic

\$39.99

1 Action Throat Mic with

Acoustic Ear Tube

\$39 99

andard(s). Operation is subject to the following two conditions: (1) this device ay not cause interference, and (2) this device must accept any interference cluding interference that may cause undesired operation of the device.

appareils radio exempts de licence. L'exploitation est autorisé ons suivantes: (1) l'appareil ne doit pas produire de brouillage, e l'appareil doit accepter tout brouillage radioélectrique subi mêm st susceptible d'en compromettre le fonctionnement.