

# QUICK GUIDE

## RF Keyboard & Mouse Combo




### Specification :

- (1) Input Voltage : DC 3V(min).
- (2) Power Consumption : **Keyboard** : 3 mA (max),  
**Mouse** : 8 mA (max).
- (3) Available Distance : 10 m(max).
- (4) Characters per Inch : 1000 CPI.
- (5) Wireless RF : 2.4 GHz.
- (6) System Requirements : Windows 7 / Vista / XP / 2000.

## 1. Package Contents :

(1) Keyboard



(2) Mouse (3) Receiver (4) Battery




### Specification :


- (1) Input Voltage : DC 3V(min).
- (2) Power Consumption : Keyboard : 3 mA (max),  
Mouse : 16 mA (max).
- (3) Available Distance : 10 m(max).
- (4) Characters per Inch : 1000 CPI.
- (5) Wireless RF : 2.4 GHz.
- (6) System Requirements : Windows 7 / Vista / XP / 2000.

## 2. Install the Batteries :

(a) Keyboard




(b) Mouse




## 3. Installation :

A) Turn ON the computer.  
Connect the receiver to the PC via USB port.



B) ID Select  **Important :**  
**ID connect for Keyboard & Mouse**


Plug-in the receiver. the LED on receiver will flash for 30 seconds. Press ID button on Keyboard or Mouse within 30 seconds. When ID matched, the LED will stop flashing. Then the Device could work.




## Function :

(a) When battery is running out of electric capacity, LED will start flashing in order to indicate user that the capacity is empty.

(1) Mouse



(2) Keyboard



(b) Power Switch :

(1) You can turn ON / OFF the power of Mouse by this power switch as you want to extend the batteries' life.



## Troubleshooting :

### Wireless RF Keyboard & Mouse not detected

**If the Keyboard & Mouse don't respond to activity, follow this steps :**

- (1) Ensure that the receiver cable is properly connect to the USB ports.
- (2) Ensure that the batteries have been installed correctly.
- (3) Ensure that you have established a connection between the RF receiver, the mouse and the keyboard.

**If the RF Keyboard & Mouse don't respond to activity after replacing. The batteries, follow these steps :**

- (1) Ensure that the batteries have been installed correctly.
- (2) Ensure that the batteries are not discharged.
- (3) Ensure that you have established a connection between the RF receiver, the mouse and the keyboard.

**This device complies with part 15 of the FCC rules. Operation is subject to the following**

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Federal Communications Commission Requirements. The equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.