APPS

To show your **app menu**, touch **O**.

- To scroll, flick up or down.
- To open an app, touch it.
- To close the app menu, touch Back 5.

Tip: To show the last eight apps you opened, touch and hold Home <u></u>.

To **download** new apps from Android Market[™], touch **o** > **a Market**. Touch Search **O** to find an app, or touch **My apps** to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: Touch Menu ≡ > **Settings** > **Applications** > **Unknown sources**.

Tip: Choose your apps and updates carefully, from trusted sites like **a Market**, as some may have an impact on your phone's performance—see **"CHOOSE CAREFULLY"** on page 15.

Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

To **move or uninstall** your apps, touch Menu \equiv > **Settings** > **Applications** > **Manage applications**. Touch an app in the list to show details and options.

On your computer, you can browse and manage apps for all your devices powered by Android[™] at <u>market.android.com</u>.

CHOOSE CAREFULLY

Apps are great. There's something for everyone. Play, communicate, work or have fun. But remember, choose your apps carefully. Here are a few tips:

- To help prevent spyware, phishing or viruses from affecting your phone or privacy, use apps from trusted sites, like **Market**.
- In Market, check the apps' ratings and comments before installing.
- If you doubt the safety of an app, don't install it.
- Like all apps, downloaded apps will use up memory, data, battery and processing power—some more than others. For example, a simple battery level widget will use less than a streaming music player app. After installing an app, if you're not happy with how much memory, data, battery or processing power it's using, uninstall it. You can always install it again later.
- Just like web browsing, you may want to monitor children's access to apps to help prevent exposure to inappropriate content.
- Certain apps may not provide completely accurate information. Take care, especially when it comes to personal health.

PHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows phone status. The left side shows new messages or events (for details, flick the bar down).




	network strength	5	battery strength
9	new voicemail	;)	new text message
8	Bluetooth™ on	*	Bluetooth connected
((•	Wi-Fi connected	≁	flight mode
Ŷ	USB connected	0	alarm set
Ø	silent ringer))))	silent ringer, vibrate on
<u>ل</u>	mute call	∔	speakerphone

PERSONALISE

add your personal touch

QUICK START: PERSONALISE

From the home screen, touch Menu => Settings > Sound or Display.



CALLS *it's good to talk*

QUICK START: CALLS

From the home screen, touch 🗐.



Tip: For quick access to contacts, see "**FAVOURITES**" on page 21.

CONFERENCE CALLS

To start a conference call, call the first number. After they answer, touch **Add call** and call the next number. When the next number answers, touch **Merge calls**. To remove individual callers, touch **Manage**.

CALL WAITING

If you are on a call and a new call arrives:

- With call waiting on, you can drag rot the right to answer the new call and put the old call on hold.
 Then, touch Swap to switch between calls, or Merge calls to combine them.
- With call waiting off, the new call goes straight to your voicemail.

To turn on call waiting, touch Menu => Settings > Call settings > Call feature settings > Additional settings > Call waiting.

EMERGENCY CALLS

Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by country. Your pre-programmed emergency number(s) may not work in all locations and sometimes an emergency call cannot be placed due to network, environmental or interference issues.

- Touch (III (if your phone is locked, then touch Emergency call).
- 2 Enter the emergency number.
- 3 Touch Call to call the emergency number.

Note: Your phone can use location based services (GPS and AGPS) to help the emergency services find you. See "Location services" in your legal and safety information.

COOL DOWN


In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see "Cool down" messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in "Cool down" mode, only emergency calls can be made.

CONTACTS

contacts like you've never had before

QUICK START: CONTACTS

From the home screen, touch $\Box > \Box$ Contacts.



FAVOURITES

For quick access to a favourite contact, open the contact, then touch the star next to their name. To show your favourites, touch () and touch **Favourites** at the top.

To add a shortcut to your favourites, touch and hold a blank spot on your home screen, then touch Folders >

Starred contacts. You can also add a shortcut for an individual contact: Touch and hold a blank spot on your home screen, then choose **Shortcuts** > **Contacts**.

STORAGE & TRANSFER

When you create a new contact, your phone asks if you want to store it in your Google™ account, phone memory or SIM card. Contacts in all three places appear in your **Contacts** list, but if you change phones:

- Contacts in your Google™ account can download when you log into your Google account on a new Android™ device. You can open these contacts from any computer at <u>contacts.google.com</u>.
- Contacts on your SIM card can load to a new device when you insert your SIM card.
- Contacts in your phone memory stay in your old phone, unless you export them.

To import or export contacts between your phone memory and a SIM or memory card, touch •> > Contacts, then touch Menu => Import/export.

MESSAGING

sometimes it's better to text or email...

QUICK START: TEXT MESSAGING

From the home screen, touch \boxed{O} > $\boxed{\times}$ Messaging.



Tip: To see more messages, flick or drag up.

EMAIL

 To set up Google or Corporate (Microsoft™ Exchange server) accounts, touch Menu => Settings > Accounts & sync > Add account. For details, contact the account provider.

To set up standard email accounts (not Gmail[™] or Microsoft[™] Exchange), touch **○** > **○ Email** and follow the wizard. To add more standard accounts, open **○ Email** and touch Menu **○** > **Accounts** > Menu **○** > **Add account**. For details, contact the account provider.

To open email, touch > Email or Gmail.
Touch a message to open it.

Tip: Touch Menu \blacksquare for options like Refresh or Search.

 To create an email, touch **○** > **[™]** Email or [№] Gmail, then touch Menu **=** > Compose.

Tip: Touch Menu 🗐 for options, like Attach or Add Cc/Bcc.

Gmail synchronises with your Google™ account mail, which you can open from any computer at <u>mail.google.com</u>. To stop synchronising with your account, touch Menu => Settings > Accounts & sync, touch your Google account, then deselect Gmail.

VOICEMAIL

When you have a new voicemail, **oo** shows in the status bar at the top of your screen. To hear voicemails, touch (III) then touch and hold **1**.

If you need to change your voicemail number, on the home screen touch Menu $\textcircled{}{}=$ > Settings > Call settings > Call feature settings > Voicemail settings. For your voicemail number or other details, contact your service provider.

TEXT ENTRY

keys when you need them

QUICK START: TEXT ENTRY

To **change the keyboard**, touch and hold a blank spot in a text box. A menu opens, where you can choose **Input method** > **Android keyboard** or **Swype**.

Note: Swype is not available in all regions. Your keyboard might change depending on what you're entering.

Swype lets you drag your finger over the letters of a word, in one continuous motion.



To enter a word, just trace a path through the letters. To capitalise, go above the keyboard. For double letters, circle the letter. Android keyboard lets you enter letters by touching them one at a time.



Symbols/numbers

TEXT ENTRY DICTIONARY

Your phone's dictionary stores special words or names to recognise when you enter them.

To open your dictionary, from the home screen, touch Menu \blacksquare > Settings > Language & keyboard > User dictionary.

- To add a word, touch Menu ≡ > Add.
- To edit or delete a word, touch and hold it.

SCHEDULE

helping you stay in control

QUICK START: SCHEDULE

From the home screen, touch \bigcirc > $\boxed{31}$ Calendar.



ALARM CLOCK

To set an alarm (like to wake up), touch $\boxed{O} > \boxed{Clock}$, then touch the O alarm.

- To turn an alarm on or off, touch O next to it.
- To add an alarm, touch Add alarm, then enter alarm details.
- To change an alarm, touch the time.