

# MOTOROLA EX225

LIFE.  POWERED.



**SAR** This product meets the applicable SAR limits of 1.6 W/kg (FCC) and 2.0 W/kg (ICNIRP). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the legal and safety information packaged with your product.

**Note:** When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 2.5 cm (1 inch) from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

68016601001

## WELCOME

MOTOKEY™ SOCIAL is a phone with exciting features including music, photo, video, browsing, and more—with an easy to use QWERTY keypad.


- **Music.** Instantly play your music. Just open your media player and select a playlist.
- **Photos.** Use your phone's camera to take photos and send them to your friends.

We've crammed all the main features of your phone into this handy guide, and in a matter of minutes we'll show you just how easy your phone is to use. You may be surprised at what you discover.

**Note:** Your phone may not appear exactly as the images in this guide.

**Caution:** Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information in this guide.

## YOUR PHONE



## LET'S GO

- 1 Cover off
- 2 SIM in
- 3 microSD in (optional)
- 4 Battery in
- 5 Cover on
- 6 Charge up

## BASICS

### Turn it on & off


Press and hold **Power/Lock** key (on top of the phone) for a few seconds to turn the phone on/off.


### Touch tips


- **Touch:** Choose an icon or option.
- **Drag/Flick:** Scroll/move slowly (drag) or quickly (flick).

### Menu navigation

Touch  to open the main menu.

Press Home  to close any menu or app screen and return to the home screen.

Touch  to go back.

Drag  down to open the settings menu.

Flick the menu screen left or right to view more panels.

## PERSONALIZE



### Profiles

Your phone has different profiles. You can customize ringtones, alerts, and volumes for each profile.

Touch  >  > **Profile**, then select from these profiles:



- **General:** Standard profile default setting.
- **Silent:** Ringtone is off, vibrate is off.
- **Outdoor:** Ringtone and key tone volume set to maximum.
- **Meeting:** Vibrate is on, ringtone is off.
- **My style:** Set your own ring style.

### Display settings

To set display settings such as wallpaper, touch  >  > **Phone settings** > **Display**.






### Date & time

Set date, time, time zone, and formats:


touch  >  > **Phone settings** > **Time and date**.



## MESSAGES

### Send an SMS or MMS

- 1 Touch  >  > **More** > **Message** > **Write message**.
- 2 Enter your message.
- 3 Touch the icons at the bottom of the screen to add pictures, videos, and more.
- 4 Touch  > **Enter recipient or Add from Phonebook**.
- 5 Touch  > **Done** >  > **Send**.




### Read messages

When you receive a message, your phone plays an alert and shows the new message indicator  at the top of the screen.

To read the new message, touch **View**. To read messages stored in your inbox, touch  >  > **More** > **Message** > **Inbox**.

## CALLS

### Make calls

From the home screen, touch  >  > **Dial pad**, then enter a number and touch .


### Answer calls


When your phone rings or vibrates, touch .

### End a call




Touch .

### In-call options


During a call, touch  to **Hold**, **End**, make a **New call**, and more.

Touch  to mute your call.

### Redial number

- 1 Touch  >  > **Call log**.
- 2 Highlight the contact you want to call, then touch .

### Emergency calls

To call an emergency number, enter the emergency number and touch . Your service provider programs emergency phone numbers, (such as 112 or 911), that you can call under any circumstances, even when your phone is locked.


Emergency numbers vary by country. Your phone's pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

## TIPS & TRICKS

### Recent calls

To see your **Missed Calls**, **Dialed Calls** and **Received Calls**, touch  >  > **More** > **Call log**.

### Voicemail






From the home screen, touch , then touch and hold **1**. If your voicemail number is preset, you will connect.

### Backlight time

To set how long your backlight stays on, touch  >  > **Phone settings** > **Misc. settings** > **LCD backlight**.


### Battery tips


Want to extend your battery life? Try these:




- Turn off Bluetooth™ power: Touch  >  > **Connection** > **Bluetooth** > **Power** > **Off**
- Turn off WiFi: Touch  >  > **Connection** > **WiFi** >  > **Disable WLAN**

## MUSIC

Touch  >  > **More** > **Audio player**



Press Home  to use another app. Your media continues to play. If you use **FM radio** the media player is turned off.

**Tip:** To create a new playlist, touch  >  > **More** > **Audio player** > **Playlists** >  > **New**.

## MENU MAP


- Dial pad**
  - More**
    - Facebook\*
    - Settings
    - Dial pad
    - Phonebook
    - Call log
    - Message
    - Email
    - Favorite Contacts
    - Esmoze Pushmail
    - Opera Browser
  - Camera**
  - More**
    - Camera
    - Video player
    - Sound recorder
    - Image viewer
    - Photo editor
    - Audio player
    - FM radio
    - Picture share
    - Games and apps
  - More**
    - Alarm
    - World clock
    - File manager
    - Calendar
    - Tasks
    - Notes
    - Calculator
    - Currency converter
    - Unit converter
    - Stop watch
    - Ebook
    - RSS
    - Weather
    - Internet
  - More**
    - YouTube\*
    - MySpace\*
    - Gmail\*
    - Orkut\*
    - mTweet\*
  - More**
    - WiFi
    - 3G\*
    - Hot spot\*
    - Back light
    - Bluetooth
- This is a standard main menu layout. Your phone's menu may be a little different. Flick the menu screen left or right to view more panels.  
\* Network/carrier dependent

## YOU TUBE™


The YouTube user-generated content web site lets you share videos with YouTube users everywhere. You don't need a YouTube account to browse and view videos.

Touch  >  > **YouTube**

**Note:** If you don't have a YouTube account, visit [www.youtube.com](http://www.youtube.com) to find out more.





To **Search**, **Upload**, or **Share** videos, touch .

### Watch videos


See popular video categories, like Most viewed, Most discussed and Most recent. Touch a category, then touch the video to start playing it. To see more video categories, touch  > **Categories**.


## CONTACTS


### Create contacts

Touch  >  > **Phonebook** > , enter the contact name and details, then touch  > **Save**.

### Call contacts



Touch a contact, then touch .



**Tip:** Press the volume keys to scroll to a contact, then touch  to call.




## BLUETOOTH™

### Turn on or off



Touch  >  > **Connection** > **WiFi**

Touch  >  > **Connection** > **Bluetooth** > **Power** > **On or Off**

When Bluetooth power is on, the Bluetooth indicator  appears in the home screen.









### Connect new bluetooth devices

To connect with a new device, you need to pair with it. You only need to do this once for each device.

- 1 Make sure the device you are pairing with is in discoverable mode (see device instructions).
- 2 Touch  >  > **Connection** > **Bluetooth** > **My devices** > **Search new device**.
- 3 Your phone lists the devices it finds within range. Select a device to connect.
- 4 If necessary, enter the device passkey (like **0000**) to connect to the device.



## MEDIA

### Photos & videos

- **Photos:** Touch  >  > **Camera**. To take the photo, touch .
- **Videos:** Touch  >  >  > **Video recorder**. To record the video, touch . Touch  to stop.

After you've taken the photo or video, touch , then:


- To **send** in a message, email, or via bluetooth, touch **Forward**.
- To **delete** the photo or video and return to the viewfinder, touch **Delete**.
- To **edit** the photo, touch **Photo editor**.

To see the photos and videos you've taken, touch  >  > **More** > **Image viewer** or **Video player**.

## WEB

Use your phone's browser to surf your favorite Web sites, upload videos to a video blog, and download files and applications to your phone. Log onto your internet-based email account to check your email.

Touch  >  > **Opera Browser**

To edit browser settings, touch .

**Note:** If you can't connect, contact your service provider.

## HOME SCREEN

The **home screen** is what you see when you turn on the phone or touch Home from a menu. It's basically like this:



**Note:** Your home screen might look a little different.



## Specific Absorption Rate (FCC)

YOUR MOBILE DEVICE MEETS FCC LIMITS FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) adopted by the Federal Communications Commission (FCC). These limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values

Head SAR	GSM 1900, Wi-Fi, Bluetooth	0.909 W/kg
Body Worn	SAR GSM 850, Wi-Fi, Bluetooth	1.33 W/kg

During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out using an approved accessory or at a separation distance of 2.5 cm (1 inch). To meet RF exposure guidelines during body-worn operation, the device should be in an approved accessory or positioned at least 2.5 cm (1 inch) away from the body. If you are not using an approved accessory, ensure that whatever product is used is free of any metal and that it positions the phone at least 2.5 cm (1 inch) away from the body. If you are interested in further reducing your RF exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body. Additional information can be found at [www.motorola.com/rfhealth](http://www.motorola.com/rfhealth).