

verizon

Start
Here

DRÖID
RAZRM
BY MOTOROLA



My Verizon

You're now connected to Verizon 4G LTE. Lightning fast, lightning strong. For more information, visit verizonwireless.com/4GLTE.

REGISTER at verizonwireless.com/myverizon, to learn how to use your smartphone:

- 1 Go to **My Verizon**.
- 2 Click on **My Device**.
- 3 Click on **Support**.
- 4 Click on **Interactive "How To" Simulator**.

My Verizon allows you to manage your account, pay your bill, purchase accessories & more.

Assistance is at your fingertips anytime at verizonwireless.com.

Customer Service is at your disposal at 1-800-922-0204 or at any Verizon Wireless Store.

A User's Guide is available on demand—simply download at support.vzw.com/phones, or call 1-800-734-5870 to order a copy.

Note: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.

Smartphone Features




Warning: Please use only an approved charging accessory to charge your device. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void your warranty.

Tip: In the unlikely event that your device becomes unresponsive, try a **forced reboot**—press and hold both the **Power key** and the **Down Volume key** for up to 10 seconds.

Note: Your home screen might look a little different.

Setting Up Your Smartphone

Assemble & Charge



Note: This product uses a non-removable battery.

Note: A Subscriber Identity Module (SIM Card) is a "smartcard" that houses personal information, such as your mobile smartphone number, calling plan, account information, and content, such as contacts, text messages, and call history. The Verizon Wireless 4G Micro SIM Card is compatible with any Verizon Wireless 4G certified device. You can move the 4G Micro SIM Card from one device to another and your wireless service will work seamlessly as long as you have a compatible device and service plan. To see which devices are compatible with the Verizon Wireless 4G Micro SIM Card, visit verizonwireless.com/certifieddevice.

Set Up & Go



After you power up, create or log into a Google™ account to access all of your Google services. Registration is secure and only takes a few minutes.

Tip: To learn more about your smartphone, touch Apps (⋮) > **Help** at any time.

Tip: To quickly change some common smartphone settings, flick the home screen right to go to **Quick settings**. To learn more about each setting, touch (?) in the upper right.

Unlock & Lock Touchscreen

To unlock the screen, press the Power key, then touch (⏻) and flick to **Unlock**.

To lock the screen, press the Power key, or let the screen time out (don't press anything).

Make & Answer Calls

To make a call, touch **Phone**, enter a number, then touch (☎).

Tip: When the screen is locked, touch (⏻) and flick to **Phone**. To answer a call, touch (☎) and flick to (📞).

To send an incoming call to your voicemail, touch (☎) and flick to (📞).

To send a pre-set text message to the caller, touch (☎) and flick to (💬). Select a message to immediately send it.

Tip: When you hold your smartphone to your ear, the display goes dark to prevent accidental touches. When you move the smartphone away from your ear, the display lights up again.

Tip: To silence an incoming call alert, press the Power key or the volume keys.

Ringtones

Make your smartphone dance to your tune. Choose a ringtone, change the tone, or silence your smartphone.

To personalize your ringtones, touch Apps (⋮) > **Settings** > **Sound** > **Phone ringtone** or **Default notification**.

Tip: To quickly change your ringtone, flick the home screen right to go to **Quick settings**, then touch **Phone ringtone** at the top.

To silence your smartphone and make it vibrate for incoming calls, touch the Down Volume key one or more times until the smartphone vibrates and you see (🔇) in the status bar.

To set a personal ringtone for a contact, touch Apps (⋮) > **People** > **contact** > Menu (☰) > **Set ringtone**.

Wi-Fi

To use a Wi-Fi network for Internet access, touch the status bar at the top of the home screen and drag it down. Touch the **Wi-Fi networks available** notification to select a preferred network.

To quickly activate Wi-Fi, flick the home screen right to go to **Quick settings**, then touch the **Wi-Fi** power switch to turn it (ON) and scan.

Bluetooth®

To connect your smartphone with a Bluetooth headset or other device, you need to pair with it. You only need to do this once for each device—to connect again, just turn on the device.

- 1 Make sure the Bluetooth device you are pairing with is in discoverable mode.

Note: Refer to the guide that came with the Bluetooth device for details.

- 2 Flick the home screen right to go to **Quick settings**, then touch the **Bluetooth** power switch to turn it (ON) and scan.

- 3 Touch the device name to connect.

- 4 Touch **OK**, or enter the device passkey (like 0000) to connect to the device. When the device is connected, the Bluetooth connected indicator (📶) appears in the status bar.

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

Backup Assistant™ Plus

Backup Assistant and Media Manager are now Backup Assistant Plus. Protect your contacts and access your media when you need it on the go or at home. Go to verizonwireless.com/baplus.

Set Up Your Google™ Account

Now your Gmail™, Google contacts, and Google calendar events can all be loaded to your smartphone automatically.

Record your Google account information. Please keep this document in a safe place.

Username: _____@gmail.com

Password: _____

Note: You don't need to have a Google account to use your smartphone.



This product meets the applicable limit for exposure to radio waves (known as SAR) of 1.6 W/kg (FCC & IC). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.



Set Up Other Email Accounts

Touch Apps > **Settings** > **Accounts & sync** > **ADD ACCOUNT** > **Email**. For account details, contact the account provider.

Set Up Voicemail

Dial ***86 (*VM)**. If you hear a greeting, touch **#** to interrupt it, and follow the setup tutorial.

Access Voicemail

From your smartphone: Dial ***86**. When you hear the greeting, touch **#** to interrupt, follow the prompts.

From any phone: Dial your wireless number. When you hear the greeting, touch **#** to interrupt, follow the prompts.

Note: Voice mailboxes not set up within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup tutorial.

Visual Voicemail

View a list of messages without dialing into a mailbox. Listen or erase with the touch of a button.

Apps & More

Play it up with music, ringtones, wallpapers, apps and games. Keep up with Twitter and Facebook®. For details and pricing, go to verizonwireless.com.

Note: Data charges may apply.

Installing Apps

Hundreds of thousands of apps are available to download from Google Play™ Store.

From the home screen, touch **Play Store**.

To view all of your installed apps, touch Apps > **All Apps** > **Downloaded**.

Verizon Tones

Search, preview, purchase and manage ringback tones and ringtones from your favorite artists all in one place. Go to verizonwireless.com/mediastore.

Verizon Video

Watch full episodes of your favorite shows. Get hundreds of TV shows, live sports and events. Go to verizonwireless.com/video.

Media Store

Find apps for entertainment, travel, productivity, navigation, ringback tones, ringtones, games, wallpaper and more. Go to verizonwireless.com/mediastore.

Email

Check email on the go with popular Internet-based email accounts, including Yahoo!® Mail, AOL® Mail, Gmail™, Windows Live® Hotmail® and **Verizon.net**.

Mobile Web

Take the Internet on the go. You can reach the latest news, get the weather and follow your stocks. From the home screen, touch **Browser**.

Verizon SafeGuards

Family and Safety Apps & Services. Get the most robust parental controls. Go to verizonwireless.com/safeguards.

Location Based Services

This smartphone can determine its location, which is useful for services such as navigation, shopping and weather. For your safety, it's defaulted to only acquire your location when you dial 911. To use Location Based Services, go to Apps > **Settings** > **Location services**.

Note: Your wireless device can determine its (and your) physical, geographical location ("Location Information") and can associate Location Information with other data. Additionally, certain applications, services and programs are capable of accessing, collecting, storing and using Location Information and disclosing Location Information to others. You should use caution when determining whether or not Location Information should be made available to others and you should review any applicable third party policies before providing access. To limit potential unauthorized access to your Location Information, Verizon Wireless offers various mechanisms and settings to manage access to location data. By enabling location settings you are permitting third party access to Location Information through software, widgets or peripheral components you choose to download, add or attach to your wireless device or through web access, messaging capabilities or other means and you are authorizing Verizon Wireless to collect, use and disclose your Location Information as appropriate to provide you with any location services that you enabled.

VZ Navigator®

Get premium GPS voice navigations and 3D maps with spoken real-time traffic alerts. Find movie times, event info and gas stations. Go to verizonwireless.com/navigator or verizonwireless.com/navigator.

VZ Navigator® Global

Enjoy the benefits of VZ Navigator when you travel overseas, and don't let unfamiliar areas and road signs in different languages keep you from arriving at your destination on time. Go to verizonwireless.com/navigator.

Global Ready™

Verizon Wireless keeps you connected around the corner and around the world. For up-to-date information on destinations and rates go to verizonwireless.com/tripplanner or verizonwireless.com/tripplanner.

Global Travel Program

Voice service available in more than 220 countries and data available in more than 205 countries — including more than 150 countries with 3G speed. This is the perfect short-term solution for the occasional or infrequent global traveler when traveling outside of the U.S. to GSM locations. For more information, go to verizonwireless.com/globaltravel.

Customer Information

Your Wireless Device and Third Party Services:

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information:

This smartphone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this smartphone that have not been tested yet for use with hearing aids. It is important to try the different features of this smartphone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this smartphone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or smartphone retailer.

Copyright & Trademarks

Motorola Mobility LLC
Consumer Advocacy Office
600 N US Hwy 45
Libertyville, IL 60048

www.motorola.com

Note: Do not ship your product to the above address. If you need to return your product for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-800-734-5870 (United States)
1-888-390-6456 (TTY/TDD United States for hearing impaired)
1-800-461-4575 (Canada)

Certain features, services and applications are network dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

Note: The images in this guide are examples only.

MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. DROID is a trademark of Lucasfilm Ltd. and its related companies. Used under license. Google, the Google logo, Google Maps, Google Talk, Google Latitude, Gmail, YouTube, Google Books, Google Docs, Google Goggles, Google Finance, Google Local, Google Maps Navigation Beta, Google Calendar, Google Play and Android are trademarks of Google, Inc. All other product or service names are the property of their respective owners.
© 2012 Motorola Mobility LLC. All rights reserved.

Caution: Motorola does not take responsibility for changes/modification to the transceiver.

Product ID: DROID RAZR M (Model XT907)
Manual Number: 68017155001-A