

**jelly bean.**  
Reversible Sling

**munchkin.**



4 - 24 months  
18 - 35 lbs  
(8-15kg)

Model#: MK0071

CCD-0095-000 Rev1

## Safety Precautions

(Please carefully read all instructions BEFORE wearing your Jelly Bean® Reversible Sling. Please keep instructions for future use.)

**⚠️ WARNING:** FAILURE TO FOLLOW THE MANUFACTURER'S INSTRUCTIONS CAN RESULT IN DEATH OR SERIOUS INJURY.

### SUFFOCATION HAZARD

- Ensure the infant's face is above the fabric, visible, and free from obstructions at all times.
- Babies at greatest risk of suffocation include those born prematurely, those with respiratory problems and those under four months of age.
- Ensure the baby does not curl into a "C" position with the chin resting on or near the chest. This position can interfere with breathing, even if nothing is covering the nose or mouth.

**FALL HAZARD** - Leaning, bending over, or tripping can cause baby to fall. Keep one hand on baby while moving.

Follow the manufacturer's recommended weight range when using carrier. Never use this carrier for a preterm infant without seeking the advice of a healthcare professional.

Read and follow all printed instructions.

- Check for ripped seams, torn straps or fabric and damaged hardware before each use.
- Ensure that the baby is safely positioned in the sling carrier according to manufacturer's instructions for use.
- Never leave a baby in a sling carrier that is not being worn.
- Check on the baby often. Ensure that the baby is periodically repositioned.
- If using the sling while breast feeding, always move the baby's face away from the breast after the baby is done feeding.
- Never use a sling carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Never place more than one baby in the sling carrier. Never use/wear more than one carrier at a time.
- Never use sling carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.
- Never wear sling carrier while driving or being a passenger in a motor vehicle.



**Right**

Chin up; Face visible; Nose and mouth free



**Wrong**

Baby's face is covered



**Wrong**

Baby is too low



**Wrong**

Baby is hunched with chin touching chest



**Wrong**

Baby's face is pressed tight against wearer

2

## Simple Sizing Guide

Sling Size	T-Shirt Size	Body Type
S/M	S/M	Short & average build or Tall & thin build
L	L	Tall & average build or Short & full build

NOTE: This is a guide to provide an approximate size and may not be exact for each person.  
4 - 24 months, 18 - 35 lbs (8-15 kg)

## Finding the right fit

You will want the sling to fit snugly but feel comfortable. If you put your baby in the sling and it feels too tight, you need a larger size. If the sling is too loose and baby doesn't feel secure then you need a smaller size. With baby inside the sling, the baby should sit in line with your hip bones or above. The bottom of the pouch should be somewhere around your belly button. If it's much lower than this, your sling is too big. The fit around the baby should be snug and create a womb-like feeling. The baby may look squished but as long as you and the baby are comfortable then you have the right size.

See illustration below for a guide to where the sling should lay. Please remember this is a guideline.



For the front carry and tummy to tummy positions, the built-in padding should be worn on the outside facing away from your body. For the hip and back carry, built-in padding should be on the inside.

Please note, no matter which position you are using, your baby's bottom should always rest on the seam, which is curved to create a deep seat. For the upright positions, the seam should be just off center from your belly button, about halfway between your belly button and hip bone. For the hip carry position the seam should be at your hip.

3

## How to fold and put on



1. This is the sling unfolded. Make sure it is folded before wearing.



2. Fold the sling inside itself.



3. This makes the sling into a two-layered tube.



4. Put the sling over your head so it rests on one shoulder with seam at the middle of your chest.



5. The curved seam will now be in front creating a pouch for your baby.



6. Make sure the fabric lies flat across your back and covers your shoulder to ensure comfort.

## Front Carry (4-24 months/18-35 lbs/8-15 kg)



1. Put the sling on as previously instructed with the padding on the outside.



2. Hold baby up high on your chest with baby's back towards you.



3. Open the pouch, cross baby's legs and lower baby's bottom into the sling.



4. Adjust the fabric to make sure baby is supported and comfortable.



## Hip Carry (4-24 months/18-35 lbs/8-15 kg)



1. Put the sling on with the padding on the inside. Hold your baby up onto your shoulder.



2. Put baby's feet all the way through. Slide the sling around so the seam is in line with baby's spine.



3. Open the folds of the pouch to make a seat. Pull the inside fabric layer down and completely under baby's bottom and lower baby into seat.



4. The bottom padded rail should be under baby's knees. Baby's knees should be higher than her bottom so her weight is not on her legs.

## Additional Carrying Positions:

### Back Carry (6-24 months/22-35 lbs/9-15 kg)



1. Put baby into Hip Carry position. (see Hip Carry instructions)



2. Then slide the entire sling along with baby around to your back.

### Tummy To Tummy (4-24 months/18-35 lbs/8-15 kg)



1. Slide your baby in feet first with legs tucked inside the sling.



2. Lean forward slightly allowing your baby's bottom to rest deep in the pouch.



3. Lay baby's head and shoulders back into the upper part of the sling so that baby's back is supported. Make sure baby is resting against your chest.

## Care Instructions

Machine wash cold, separately, on gentle cycle. Do not bleach. Line dry. Do not iron. Do not dry clean.



800.344.BABY (2229)  
[www.munchkin.com](http://www.munchkin.com)

PRODUCT AND DESIGN ARE TM & ©2007-2012 MUNCHKIN, INC. MUNCHKIN, JELLY BEAN AND IT'S THE LITTLE THINGS ARE TRADEMARKS OR REGISTERED TRADEMARKS OF MUNCHKIN, INC. 16689 SCHOENBORN ST., NORTH HILLS, CA 91343. MADE IN CHINA/FABRIQUÉ EN CHINE.