

2/ P.03

*

FCC WARNINGS

This device complies with part 15 of the FCC rules, operation is subject to the condition that this device does not cause harmful interference.

How to Obtain a GMRS License?

You must obtain an FCC license (or be an immediate family member of someone who is already licensed) before you may transmit with a GMRS radio.

To apply for a GMRS license, you must complete and return a Form 605 to the FCC. You can obtain a copy of the FCC Form 605 and its instructions by calling: 1-888-CALL-FCC. You can also obtain a copy from the FCC's Web site: www.fcc.gov/formpage.html

You can also apply for a GMRS license directly on the Web.

Applicants must also submit an FCC Form 159 (Remittance Advice). It is available from the same sources mentioned above.

As of September 2000, the cost of obtaining an FCC license in the GMRS is \$85. This includes a \$50 application fee, and a usage fee of \$35 (\$7 per year for the five-year GMRS license). This \$85 fee total must be submitted along with the application.

PRECAUTIONS

- Do not modify or attempt to adjust the transceiver for any reason.
- Avoid extremes in exposure to water, heat, and cold. This transceiver is weather resistant but not waterproof.
- Do not expose the transceiver to long period of direct sunlight, nor place the transceiver close to heating appliances.
- Do not place the transceiver in excessively dusty areas, humid areas, wet areas, nor on unstable surfaces.
- If an abnormal or smoke is detected coming from the transceiver, immediately switch OFF the power and remove the batteries from the transceiver. Contact your dealer.

Caution: To maintain compliance with the FCC's RF exposure guidelines, hold the transmitter and antenna at least 2 inch (5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face. If you wear the headset on your body while using the headset accessory, use only the manufacturer's supplied belt clip for this product and ensure that the antenna is at least 1 inch (2.5 centimeters) from your body when transmitting.

Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.

1

Safety Information

Your wireless handheld portable transceiver contains a low power transmitter. When the Push-to-talk(PTT) button is pushed it sends out radio frequency (RF) signals.

This device is authorized to operate at a duty factor not to exceed 50%. In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless devices.

Features

- Up to 7 miles range without Repeater-Assisted Communications
- Total 23 Channels
 1. 14 Main Channels with 38 CTCSS Sub-channels
 2. 7 Repeater-Assisted Channels with 38 CTCSS Sub-channels
 3. 2 Emergency Channels
- Build-in VOX Function with adjustable Mic sensitivity
- Adjustable Squelch Control
- Time-Out-Timer (Transmitter operation timer)
- Auto channel Scan
- Channel Memory Presets
- Multi-function Back-lit LCD Display
- Talk Confirmation Tone and Call / Ring Button
- Detachable Belt Clip
- Auto Battery Saver
- External Power (DC 9V) and External Microphone Speaker Jacks

UNPACKING

Carefully unpack the transceiver. We recommend that you identify the items listed below before discarding the packing material.

- Transceiver1
- Belt Clip1
- Instruction Manual1

2

11-OCT-2001