
Model: YLT-40C

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre

USE AND CARE GUIDE

INDOOR WIRELESS REMOTE CONTROL



THANK YOU

We appreciate the trust and confidence you have placed in Defiant through the purchase of this indoor wireless remote control. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Defiant!

(1) This device may not cause interference; and

le fonctionnement.

Safety Information

Federal Communications Commission Interference Statement

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and the receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.
- FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. Store indoors when not in use.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

RATINGS
125 VAC, 60 Hz
15 A General Purpose
15 A Resistive
625 W Tungsten
500 VA Electronic Ballast
1/3 HP Motor

Product Description



WARNING: For indoor use only

1. LED power indicator light: The LED power indicator light the receiver is on.

2. Outlets:


The outlet located on the front of the receiver allow the user to plug an array of devices into it.

Plug the lights or devices to b controlled by the remote into the outlet.

3. Remote control:

- ON: When the on button is pressed, it will override the receiver's current program to on function.
- □ OFF: When the off button is pressed, it will override the receiver's current program to off function.
- Remote indicator light: The LED light indicates that the ON or OFF button is being pressed.





Operating Instructions

Using the remote control

- Plug the device you wish to be controlled into the receiver (outlet).
- To activate the receiver, press the "ON" button of the remote control. The green LED of the remote control will illuminate momentarily and the LED of the receiver will remain illuminated.
- Remove the insulation tab from the battery compartment.
- To turn the receiver OFF, press the "OFF" button of the remote control. The LED on the receiver will shut off.

Maintenance

Replacing the battery



WARNING: Do not mutilate or place the battery in a fire. The battery may burst or release toxic materials. Do not short circuit or reverse polarity as this may cause burns.

- Remove the battery compartment cover from the back of the remote control by sliding the cover in the direction that its threads curve.
- Remove the old battery and place a new DC 12V Type A23 battery into the battery compartment, correctly observing the polarity indications (+/-) inside the battery compartment.
- □ Replace the battery compartment cover.
- Dispose or recycle spent/discharged batteries in compliance with all applicable laws. For detailed information, contact your local solid waste

Troubleshooting

Problem	Solution
The lights do not turn on and off via remote control.	Confirm remote operation after replacing batteries.
Remote does not turn the device on or off.	Receiver and transmitter need to be re-synched. Replug the reciever into a properly gounded outlet and within 15 seconds, press and hold the ON and OFF buttons on the transmitter for 2 seconds until the green indicator flash 3 times on the reciever.