

# True Wireless Earbuds

Instruction Manual  
2969



1. Mode Button
2. LED Indicator
3. Input Port (1)
4. Input Port (2)

## What's included:

- 2 x True Wireless Earbuds
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

## Technical Specifications:

Model: 2696

Frequency response: 20Hz-20kHz

Built-in 55mAh/3.7V lithium polymer battery in each earbud

Charging input: 5V/0.055A

It takes 2 hours to recharge from 0 to 100%.  
Playback at max. volume: up to 1 hours.

## LED Indicators:

- Solid Red: Earbuds are being charged
- The red LED will be turned off when charging completed

## ON/OFF:

- Bring the Earbuds close to your ears so you can hear the Earbuds' announcements. Press and hold the Mode Buttons on both Earbuds, until you hear "power on"announced, place the earbuds beside each other, they will automatically pair together. One earbud will flash blue slowly. The other earbud will flash red and blue, this is the Primary/Left Earbud and will be what you use to control the functions when using two earbuds at once. Once connected, you may press and hold both or either Earbuds to turn the Earbuds off.

## Bluetooth Set Up:

- Search the possible Bluetooth connections from a Bluetooth enabled device. Select pairing name "2696" from list of available devices. Once selected, the Earbuds will announce "connected." You may now play audio.

## Mode Button Function:

- Primary/Left Channel, press once: Play/Pause, Accept/Reject call
- Secondary/Right Channel, press once: Play/Pause

## Phone Functions:

- Under connected mode when phone call comes in:  
Double press the Mode button to reject  
Short press to answer  
Short press to hang up when finishing the call
- Redial: Double press the Mode button to redial the last number you called.

## SAFETY PRECAUTIONS:

1. Please read all the instructions carefully before using the product.
2. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
7. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or
8. Do not expose the device to fire or excessive

above 212°F/100°C may cause explosion.

9. Have servicing performed by a qualified repair person using only identical replacement parts.
10. This will ensure that the safety of the product is maintained.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by (ShenZhen C-Star Electronic Tech. Co., Ltd.) is under license. Other trademarks and trade names are those of their respective owners.

FCC ID : 2ABHA0039

Bluetooth Listing Declaration ID: D026370

## FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1)This device may not cause harmful interference, and  
(2)This device must accept any interference received, including interference that may cause undesired operation.

### Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not accor in a particular installation.if this equipmnet does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connectec.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The devicecan be used in portable exposure condition without restriction.