




## About the Keyboard

Your VAIO® wireless keyboard uses a standard key arrangement with additional keys that perform specific functions.



⚠ Before attempting to connect the wireless mouse to your VAIO computer, see *Connecting the Keyboard and Mouse*.


### Wireless VAIO Keyboard




KEY	DESCRIPTION
Standby 	Press the button to place the computer in Standby mode. Press the Power button or any key briefly, to resume normal operation.
S Keys	Press the S key buttons to activate specific applications.
Brightness Control	Press a button to increase (+) or decrease (-) the brightness of the monitor screen.
Mute 	Press the button to turn off the volume of the speaker. Press the Mute button again to restore sound.

*About the Keyboard*

<b>Volume Control</b> -◁ ▷+	Press a button to increase (+) or decrease (-) the volume of the speakers.
<b>Function</b>	The 12 function keys along the top of the keyboard are used to perform certain tasks. The task associated with each function key may vary from one application to the next.
<b>Numeric Keypad</b>	Use the numeric keypad area to type numbers or to perform basic math calculations. Press the Num Lock key to activate the numeric keypad. (The Num Lock indicator lights.) Press the Num Lock key again to deactivate the numeric keypad.
<b>Directional Arrows</b>	The Up, Down, Left, and Right arrow keys move the pointer on the screen.
<b>Applications</b> 	The Applications key displays a shortcut menu in certain software applications. Pressing this key is equivalent to clicking the right mouse button.
<b>Windows</b> 	The key with the Microsoft® Windows® logo, displays the Start menu. Pressing this key is equivalent to clicking Start on the taskbar.



 Under normal use, the AA batteries may last up to six months. If your wireless keyboard does not operate properly, the batteries may need to be replaced.

If your wireless keyboard is not being used for extended periods of time, remove the batteries to avoid possible damage from battery leakage.

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**Canadian DOC Statement:** This Class B digital apparatus complies with Canadian ICES-003.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: 1) this device may not cause interference, and 2) this device must accept any interference, including interference that may cause undesired operation of the device.

The transmitter frequencies are 27.095 MHz and 27.145 MHz. The RF output power is 46 nW.

**Déclaration du Ministère des Communications Canadien.** Cet appareil digital de classe B est conforme aux normes Canadiennes ICES-003.

Cet équipement a été déclaré conforme à la norme RSS-210 édictée par le Ministère canadien de l'Industrie. Son fonctionnement est soumis aux conditions suivantes: 1) l'équipement concerné ne doit pas causer d'interférences, et 2) il doit accepter toute interférence reçue, y compris les interférences risquant d'engendrer un fonctionnement indésirable.

Les fréquences du transmetteur sont 27.095 MHz et 27.145 MHz. Le pouvoir de sortie RF est 46 nW.