

Batteries are included for demonstration and they can be used until replacement. When replacing new batteries, please follow the instructions below:

TRANSMITTER BATTERY INSTRUCTIONS:

1. Locate and remove screw and slide to open battery compartment cover on transmitter.
2. Install 2 "AAA" alkaline batteries in the transmitter with positive (+) and negative (-) ends matching the compartment markings.
3. Replace the battery cover and replace the screw.

VEHICLE BATTERY INSTRUCTIONS:

1. Locate and open the battery compartment on the underside of vehicle.
2. Insert 2 "AA" batteries, with positive (+) and negative (-) ends correctly matching the compartment markings.
3. Replace battery compartment cover.

VEHICLE OPERATION:

Move switch on bottom of desired vehicle to the "ON" position.
To drive FORWARD, push the center joystick forward.
To TURN in REVERSE, pull the center joystick backward.
To STOP, release the joystick.

BATTERY SAFETY INFORMATION

- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted in position according to polarity.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not attempt to burn batteries.
- Dispose of batteries safely and correctly.
- Remove batteries if the toy will not be used for a long period of time.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short circuited.
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Batteries should be replaced under adult supervision.
- Different types of batteries are not to be mixed.

FOR BEST RESULTS:

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard or rechargeable batteries.
3. Use alkaline batteries only.

CAUTION:

Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.

F.C.C. CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CUSTOMER