#### **EASY INSTALLATION:**

- 1. One transmitter operates all three receivers.
- 2. Plug the receiver/switch into a 3-wire indoor outlet, then plug the lights or device to be switched into the receiver/switch.

Make sure that there is power to the outlet that the receiver/switch is plugged into.

- 3. The device must be mounted in a vertical position with the receptacles facing downward.
- 4. Red indicator light is lit when the indoor unit is powered on.

#### BATTERY INFORMATION AND REPLACEMENT:

- 1. On the bottom of the remote use your finger to slide out the battery holder.
- 2. Remove the used battery and insert a new CR2032 Lithium 3-volt battery with the "+" polarity mark facing up.
- 3. Slide the battery holder back inside so that it sets in place.
- 4. Dispose of old battery properly.

## **WARNING:**

Keep batteries away from children and pets.

Follow the battery manufacturer's safety and usage instructions.

- Remove battery if product is to be left unused for a long time.
- Clean the battery contacts prior to battery installation.
- Do not dispose of batteries in fire. Batteries may explode or leak.

NOTE: In case of power failure, the system will need to be reset.

#### **Remote Control**

- 1. Press: "ON" button of "1" on the transmitter, the No. 1 Receiver is power ON continuously and the red indicator will come on.
- 1.1. Press "OFF" button of "1", the No. 1 Receiver is power OFF instantly and the red indicator will go out.
- 2. Press: "ON" button of "2" on the transmitter, the No. 2 Receiver is power ON continuously and the red indicator will come on
- 2.1 Press "OFF" button of "2", the No. 2 Receiver is power OFF instantly and the red indicator will go out.
- 3. Press: "ON" button of "3" on the transmitter, the No. 3 Receiver is power ON continuously and the red indicator will come on.
- 3.1 Press "OFF" button of "3", the No. 3 Receiver is power OFF instantly and the red indicator will go out.

## **CAUTION**

- · Risk of Fire.
- DO NOT PLUG IN MORE THAN THE RATED LOAD.
- This is a Radio Frequency (RF) Device. Therefore the range of the transmitter is affected by obstructions, walls and other electronic devices.

# ATTENTION: INSTRUCTIONS FOR PROPER USE

- USE WITHIN THE ELECTRICAL RATING MARKED ON THE PRODUCT
- RATED 125 VOLTS
- Inspect periodically

## **WARNING:**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **Notice:**

Functional Range may be adversely affected by one or more of the following factors:

Orientation of the transmitter or receiver, weather, radio frequency interference, low transmitter battery and obstructions between the transmitter and receiver.



Each receiver independently controlled

Receiver