

Reset instructions for the INTELLI-SENSOR

If your water was shut off automatically by the Intelli-Sensor system, follow these steps to reset the system and restore the water flow.

Turn OFF your main water line, turn the valve handle 90 degrees to the pipe.

Locate the white sensor in your home that is beeping. Pick it up and dry it until it stops beeping. Temporarily put it somewhere dry.

Return to the shut-off room and push and hold the red button on the black receiver box for about three second until the flashing red light dims. This will reset the receiver unit and stop it beeping.

Contact a plumber. **Do not turn your water ON until the leak is fixed or isolated.**

Instructions to restore the water supply

Do not restore the water supply until the plumbing repair has been completed or the fault has been isolated by closing a local appliance valve.

Press down and hold the toggle switch on the receiver to the open position until the valve motor stops running.

Release the switch

Open a faucet in your home. SLOWLY open the main water valve to a half open position, wait fifteen to twenty seconds then SLOWLY open the valve fully.

Your system is now back to normal operation.

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Noah Technologies Inc could void the user's authority to operate the equipment.