



NT-SPL5 Way S





User Manual

Bluetooth Pairing



On/Off Button


Step 1 Long press  3 seconds to power on. The speaker enters the bluetooth searching status and the blue indicator starts blinking.



Bluetooth

Shelly-S


Step 2 Choose the Device
Find the Shelly-S from the Bluetooth name list in the phone



Indicator light keeps on

Step 3 Bluetooth Connected
In the phone, it shows Shelly-S is connected, and the blue indicator light on, which means connection succeeded and can start to play music.


Bluetooth Disconnection



Bluetooth Disconnection Button

Press it to disconnect bluetooth, and Shelly-S gets back to Bluetooth pairing mode.


Light Mode



Light Mode Button

Click to press the button, the green light mode will be switched in circulation by normally on/ slow flash/ quick flash/ light off.


AUX Connection




Device

Rubber Cover


How to easily close the rubber cover of the charging port?




Insert the head of the rubber cover first



Press the middle part of the rubber cover, done!



www.trendwooo.com
MADE IN CHINA




RoHS CE FCC


Any questions, please send an email to support@trendwooo.com for enquiry or website visit.

Basic Operation


Bluetooth Mode




1. Short press for volume up




2. Long press for next track




1. Short press when playing music for Play/Pause




2. When a call is coming, short press to answer




3. When a call is coming, double press to refuse the call



4. During a call conversation, short press to hang off




1. Short press for volume down




2. Long press for previous track


AUX IN Mode



Short press for volume up



Short press for mute



Short press for volume down

Status Description	LED Definition
Power On	The default mode is Bluetooth mode, and blue light flashes and stays in searching status. If put 3.5mm AUX IN cable, it will enter AUX IN mode, the green light is on.
Bluetooth Mode	Play/Pause: Blue light is normally on. When it is over the Bluetooth connection range, the blue light flashed back to pairing status. When the speaker is in pairing mode for over 10 minutes, it will power off automatically.
AUX IN Mode	Green light is normally on
Wait for Pairing	Blue light flashes
Bluetooth Connected	Blue light is normally on
Charging Status	Red light is on when charging. Green light is on when it is fully charged

Product Name	Shelly-S
Bluetooth Version	Bluetooth 4.1
Bluetooth range	10m
Driver Unit	40 5W
Battery Capacity	800mAh
Audio Input	3.5mm AUX IN / Bluetooth
Working time	4-5Hrs(70% volume)
Charging time	< 3Hrs/ 0.5A charging current
S/N	≥75dB
Handsfree function	Support
Dimension	96*96*43mm
Weight	158g

Frequently Asked Questions

Q:What kind of charger should we use for the speaker?

A:All common USB chargers can be used, while we suggest the ones above 5V/1A.

Q:What if there is noise or discontinuous sound when playing?

A:The speaker can be normally used within 10m under no obstruction environment. If it is over 10m or with obstruction, there might be noise or discontinuous sound.

Q:Why will the speaker shut down automatically when it is working ?

A:When there is no bluetooth pairing or AUX IN within 10 minutes, the speaker will shut down automatically to reduce power consumption.

Q: The speaker cannot connect the once-paired cellphone.

A: First, remove the Shelly-S from the cellphone's Bluetooth list and then short press the Bluetooth Disconnection Button to restart pairing mode.

Q: What is the working sequence of the speaker?

A: The priority is AUX IN input, phone call in Bluetooth mode and then playing music Bluetooth mode.

Q: The speaker cannot be started up in a normal situation.

A: Please plug in the charger and try in a few minutes.

*This speaker supports mobile phones and tablet PCs etc. Here this User Manual is illustrated based on mobile phones.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.