


NYKO

Model: 89100 PlayPad for Gear VR

1. Description:

This PlayPad works is designed to work with Samsung S7 mobile phone, when S7 is installed in Gear VR. It is a Bluetooth game pad with built-in battery.

2. Function Instruduction



3. Operation Instruction

- 1) To turn on, press the Power button for 3 seconds ,
The Power indicator will flash once.
- 2) Connect to Samsung S7 mobile phone:
 - a. Turn on S7 Bluetooth to wait for pairing.
 - b. Press Bluetooth button for 3 seconds, the BT status LED flushes before it is connected. The LED is steady blue when connected.
- 3) Use this PlayPad as regular Game Controller.
- 4) The Low Battery indicator will light when battery is low.
Connect Type-C connector to Power input to charge the device.
- 5) To turn off, press the Power button for 3 second.



NYKO

Model: 89100 PlayPad for Gear VR

FCC ID: RA3-89100

Designed in U.S.A. Made in China



FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.