

## ■ UHF Pendant Wireless Transmitter (EJ-5T)



## ■ Set up/ Installation

### Power on:

1. Press and hold for 0.5 second and the power is on. LCD backlit lights up.
2. When power is on, it will display "ON" → available channels → channel display and battery capacity → Mute LED lights blue.
3. Power is on in two seconds and receiving audio.

### Power off:

1. Press and hold for two seconds to turn the device off.
2. OFF display on screen and all indicators turned off.

### Channel select:

1. Press and hold SET button for two seconds; enter into the channel select mode.
2. When the LCD screen and numbers flashes, press + or - to select preferred channel.
3. Press SET button to confirm quit, or wait for ten seconds without any keys pressed and confirm to quit.

### Channel display:

1. LCD display channel status, press short SET key for two seconds shows the current used frequency.
2. To confirm quit without any keys pressed when exceeded for two seconds.

### Volume switch:

1. LCD screen will display current used volume size when press + or - (Vol. 1 ~ 3).
2. Press + or - to select preferred volume level and hold for two seconds to confirm or to confirm quit without any keys pressed.

### Frequency synchronization:

1. When the power is on, it will synchronize frequency or synchronize function will switch off without receiving audio signal exceeded upto ten minutes. When synchronized, MUTE indicator (blue light) and charging indicator (green light) flashes at least three times and backlit lights up.
2. To proceed synchronize, the charging indicator (green light) will be blinking (at 1 Hz) at least ten times, when use a charger HDC-520 or HDC-530. And, charging status will display.
3. The device can repeat synchronize by a charger.

## ■ Illustration

1. POWER / MUTE switch
2. Channel / Volume switch
3. LCD screen
4. Mesh head (hidden microphone)
5. External mic. Input
6. Charging indicator (built-in)
7. Aux input
8. Strap hole
9. DC charging input
10. Strap hole
11. Buckle clip
12. Charging terminal

### Mute / Listen select:

1. Press Mute button for two seconds; enter into the Mute / Talk switch mode.
2. Mute mode: LED lights red. Talk mode: LED lights green.

### Select output power/ Maximum available channels:

1. In OFF mode, press SET and POWER button to enter into the selection mode.
2. LCD screen is display maximum available channels; 640-664 MHz will display F. Press + or - to select preferred channel.
3. Press SET button to confirm quit or to wait for 5 seconds without any keys pressed and confirm to quit.
4. LCD screen is display Hi / Lo, press + or - to select preferred output power.
5. Press SET button to confirm or to wait for 5 seconds without any keys pressed.

### Charging mode:

1. LED lights red when charging, LCD battery symbol is cycle charging.
2. LED lights green when fully charged, LCD battery symbol is display steady.
3. When use a travel kit, still might use normally.
4. When device is slot into a charger stand, will off the power.
5. When device leaves a charger stand, the power is off.
6. When using a travel kit, the duration of charging time upto seven hours, it's determined full.
7. Battery error: LED status lights red and flashes when charging (at 3 Hz), LCD battery symbol screen lights flashes (at 3 Hz), shows error and it might be:
  - (1) The battery charge temperature is exceeded 60°C.
  - (2) The duration of charging time for charger stand is exceeded seven hours.
  - (3) No battery in the device.

### Others:

1. Press any buttons (except Mute button), LCD backlit lights up. LCD backlit lights off for ten seconds without any keys pressed.
2. To reset mode, press + or - at the same time and switch the power on. The initial value is set Channel: 01 (96 CH) or 00 (F CH), Volume: 2, Mute: Talk.

*Consumer Alert*

Most users do not need a license to operate this wireless microphone system. Nevertheless, operating this microphone system without a license is subject to certain restrictions: The system may not cause harmful interference; it must operate at a low power level (not in excess of 50 milliwatts); and it has no protection from interference received from any other device. Purchasers should also be aware that the FCC is currently evaluating use of wireless microphone systems, and these rules are subject to change. For more information, call the FCC at 1-888-CALL-FCC (TTY: 1-888-TELL-FCC) or visit the FCC's wireless microphone Web site at <http://www.fcc.gov/cgb/wirelessmicrophones>.